

AUTOMATIC SETTING (= recommended)

AUTO

The ventilation system is geared to obtaining good air quality automatically, based on CO₂ and/or humidity readings (if there are sensors included in the system). This is achieved as energy-efficiently as possible, by extracting polluted air only when necessary. **Ensure that manual window ventilators are open.**

MANUAL SETTINGS

With these, air quality readings are ignored and the system extracts air in line with the percentages of maximum capacity set out below. **In the medium and high settings, ensure that manual window ventilators are open.**



Low
10%*




Medium
50%*




High
100%*

Push button LED



USER CONTROLLER WITH LED IN THE CENTRE

Touch button / LED



USER CONTROLLER WITH LIGHT-EMITTING BUTTONS

TEMPORARY manual setting

15 min / 8 h = **1 x SHORT PRESS**
30 min / 16 h = **2 x SHORT PRESS**
45 min / 24 h = **3 x SHORT PRESS**




on / /

- Ventilation system to requested setting for:
- 1/2/3** x 15 min.* for a system **without** Tronic window ventilator(s)
 - 1/2/3** x 8 hours* for a system **with** Tronic window ventilator(s)

The LED will light up green for **1 second** as confirmation.

The LED for the selected setting will light up **bright white** briefly as confirmation.

For ventilation systems **with sensors**, the unit will return to 'AUTO' mode after the specified time delay ('AUTO' LED will light up bright white)



For ventilation systems **without sensors**, the unit will return to the permanent low level after the specified time delay ('Low' LED will light up magenta)



PERMANENT manual setting

1 x LONG-PRESS



on / /

- Ventilation system to requested setting until another setting is selected by the user

... until the LED lights up green for **5 seconds**.

... until the 4 LEDs briefly light up brightly. The selected setting will light up **magenta** after that.

UNOCCUPIED SETTING

2 x LONG-PRESSES



on

- Ventilation system to low setting until another setting is selected by the user

... until the LED lights up green for **5 seconds** after each press.

... until the 4 LEDs briefly light up brightly after each press. The selected setting will light up **cyan** after that.

* The times and percentages indicated are standard and may differ in line with system settings.
** Some systems do not contain temporary manual settings for pressing 2 and 3 times.

MEANING OF LED COLOURS (for operation with light-emitting buttons only)

	Temporary manual setting
	Permanent manual setting
	Unoccupied setting

	Automatic setting
	Preheating in progress in ClimaTop window ventilator
	Please wait, initialising in progress (after system restart)

This manual is to be used with the DucoBox Focus, DucoBox Silent, DucoBox Silent Connect, DucoBox Energy Comfort, DucoBox Energy Premium, DucoBox Eco, DucoBox Hygro Plus, iAV Control valve and IQ-unit. User instructions overleaf.

Your home / building has been fitted with a demand-controlled mechanical ventilation system by Duco. This system consists of a central extract unit, a duct system with vents in the kitchen, bathroom, toilet and other areas as required. This, combined with certain sensors (CO₂ and humidity) or controllers and with ventilators, as appropriate, in the windows, window frames or sliding doors for the supply of fresh air, or supply channels.

SAFETY INSTRUCTIONS

General

- The installation and commissioning of the unit are the responsibility of the installer.
- Only an accredited installer may install, connect, commission and perform maintenance on the unit other than as described in this manual.
- The unit can only be used with the appropriate Duco accessories and controller(s).
- Always adhere to the safety instructions in the manual when installing the device. Failure to comply with these safety instructions, warnings, notes and guidelines could result in damage to the unit or in personal injury for which Duco NV cannot be held liable.
- Keep the manual close to the unit.
- In order to prevent damage and/or wear, maintenance instructions require to be followed closely.
- It is recommended that you take out a maintenance contract to ensure the unit is regularly inspected and cleaned.
- The unit may only be used for applications for which it has been designed as described in the manual.
- The central extract unit is required to operate continuously, which means that it must never be switched off (legal requirement in accordance with national standards). Remove the plug from the power socket only when instructed to do so in the manual.
- The unit can be used by children over the age of 8 and individuals with physical impairments, individuals with sensory or mental impairment or individuals lacking experience and knowledge, provided they are under supervision or have received instruction on the safe use of the unit and understand the risks associated with it. Children must not play with the unit. Children must not clean or maintain the unit without supervision.
- The unit is only suitable for residential buildings and not for industrial use, such as swimming pools and saunas, unless stated otherwise.
- Modifications to the unit or to specifications stated in this

document are not permitted.

- Ensure that the inside of the unit is kept clean during installation and prior to commissioning. Dust and dirt in the unit and ducts can give rise to complaints for the occupant.
- Never immerse the unit in water.
- Never stand on the unit. Loads must not be placed on the unit.

Location/position

- The unit must not be used in places where it could get wet by being splashed or sprayed with water.
- Do not use the unit in the presence of flammable or volatile substances such as alcohol, insecticides, petrol etc.
- Do not expose the unit to the elements.
- Do not place any objects on the unit.

Electrical

- Ensure the power supply is connected as shown on the unit.
- Electrical equipment should be handled with care
 - » Never touch the unit with wet hands.
 - » Never touch the device when barefoot.
- Make sure that the electrical system to which the unit is connected complies with the stipulated conditions.
- Ensure that the electrical circuit is not damaged.
- Always ensure that before work begins, the device is isolated from the power supply by removing the power cord from the wall socket or by switching off the fuse. (Use a measuring instrument to check that this is actually the case!)
- The electronic components of the ventilation unit may be live. In the event of a fault, contact a professional installer and only have repairs carried out by expert personnel.
- If the power cord is damaged, it must be replaced by the manufacturer, after-sales support or individuals with comparable qualifications in order to prevent any hazard.
- Do not pull on the cord to remove the plug from the socket.
- Check that the voltage shown on the nameplate matches the local mains voltage before connecting the device. You will find the nameplate on the side of the unit or on the inside of the unit if you remove the cover. The power supply must be connected into the system by a qualified electrician / E / W installer.
- Always switch off the fuse if the device is not working properly or before opening it for cleaning and contact the installer.
- The unit complies with legal requirements applicable to electrical devices.

Ventilation related

- Always refer to the installer of your combustion appliance to establish whether there is a risk of flue gas ingress into the dwelling. Negative pressure in the home can be reduced by making sure that window ventilators are always adequately open.

Additional safety instructions

- Refer to the installation manual of the unit for additional safety instructions.

RECYCLING

At the end of the useful life of the unit, the user is responsible for its safe removal and disposal of its components in accordance with locally applicable laws or ordinances.

MAINTENANCE & WARRANTY

Always carry out maintenance jobs within the specified intervals. Failure to do so will be detrimental to ventilation system performance. Refer to the document [Maintenance Instructions Duco Ventilation Systems](#) on www.duco.eu for detailed instructions, and watch the instruction videos on duco.tv. Maintenance instructions for the DucoBox Energy Comfort, DucoBox Energy Premium and DucoBox Eco can be found on www.duco.eu.

The responsibility for warranty implementation lies in the first place with the installer or supplier where the DucoBox was bought. Always refer to the local installer or dealer if you have problems with the installation and/or operation of the DucoBox. Keep the serial number of the product nearby. All warranty conditions concerning the DucoBox and Duco's ventilation systems can be found on the Duco website.



FREQUENTLY ASKED QUESTIONS

How do I shut the ventilation system down completely?

The system cannot be shut down completely, this is to prevent mould growth in your house, among other things. The system can, on the other hand, be switched permanently to the low setting for maximum energy saving.

Do I need to maintain the system?

Yes, please contact your installer for annual maintenance.

What about a power cut?

You don't need to do anything: the system will restart automatically and operate correctly.

Can I switch off the LEDs on the controller?

Yes, long-press 'AUTO' to switch the LEDs on and off.

I can't hear the ventilation system, is it actually working?

Duco's ventilation systems are whisper-quiet. You can check whether the system is working by switching the system (temporarily) to the high setting and feeling an exhaust vent.

An LED is flashing on a controller or Tronic window ventilator, what is happening?

There is a network problem, refer to your installer for a remedy.

