

# **DucoSlide installation set (G0013108)**

## STEP 1:

Mechanical check, check if the panels don't encounter an obstruction both along the rail under and above

#### STFP 2

Place the panels in the middle of the system, then switch the motor on

ATTENTION: respect the colour code

The initiation procedure moves the panels back and forth, 12 cm forth, 1 sec. rest, 12 cm back

## **STEP 3:**

Single button control: press 15 seconds on the white commando, panels move slowly Double button control: press 1 second on the white commando, panels move slowly

## **STEP 4:**

Panels move back and forth on their full speed

#### STEP 5:

Motor determines the braking distance

# STEP 6:

Confirmation of end of initiation. The panels move back and forth short in the next pattern: 12 cm forth, 1 sec. rest, 6 cm back, 1 sec. rest, 6 cm back

## **STEP 7:**

This motor is initialised and ready for use. By pressing the green and/or white button you can move the panels

## **STEP 8:**

Disconnect the installation set. For more info, consult the fitting instruction