


# Catalogue

# VENTILATION SYSTEMS

# 2026



## GREEN VENTILATION

### STAY UP-TO-DATE!

Download the most current version




[link.duco.eu/cat-uk-ie](http://link.duco.eu/cat-uk-ie)

### NEW

Small. Smart. Green.



**DUKO**



# HOME OF OXYGEN

DUCO Ventilation & Sun Control provides every building with a healthy supply of oxygen. With a comprehensive range of innovative natural and mechanical ventilation systems, either combined with external solar shading or otherwise, DUCO offers the ultimate guarantee of a healthy and comfortable indoor climate. The occupant's health is,

therefore, central to DUCO. A well-thought-out combination of basic ventilation, mechanical extraction, purge ventilation and solar shading ensures optimum air quality. DUCO provides an innovative solution for residential buildings, offices, schools or care centres where everyone feels at home.

**DUCO, Home of Oxygen**

**DUCO**

# PRODUCTS

---

## VENTILATION SYSTEMS ..... 12

|   |           |
|---|-----------|
| <b>DucoBox Reno</b> .....   | <b>14</b> |
| Duco Reno System .....  | 18        |
| <b>DucoBox Silent (Connect)</b> .....   | <b>20</b> |
| Duco Silent Connect System .....  | 24        |
| <b>DucoBox Focus</b> .....  | <b>26</b> |
| Duco Focus System .....   | 30        |
| <b>DucoBox Energy Comfort (Plus)</b> .....                                    | <b>32</b> |
| Duco Energy Comfort (Plus) System 1-zone (no humidity measurement) .....      | 38        |
| Duco Energy Comfort (Plus) System 1-zone (central humidity measurement) ..... | 40        |
| Duco Energy Comfort (Plus) System 1-zone (local humidity measurement) .....   | 42        |
| Duco Energy Comfort (Plus) System 2-zone (no humidity measurement) .....      | 44        |
| Duco Energy Comfort (Plus) System 2-zone (central humidity measurement) ..... | 46        |
| Duco Energy Comfort (Plus) System 2-zone (local humidity measurement) .....   | 48        |
| <b>DucoBox Energy Sky</b> .....   | <b>50</b> |
| Duco Energy Sky System 1-zone (no humidity measurement) .....                 | 54        |
| Duco Energy Sky System 1-zone (central humidity measurement) .....            | 56        |
| Duco Energy Sky System 1-zone (local humidity measurement) .....              | 58        |
| Duco Energy Sky System 2-zone (no humidity measurement) .....                 | 60        |
| Duco Energy Sky System 2-zone (central humidity measurement) .....            | 62        |
| Duco Energy Sky System 2-zone (local humidity measurement) .....              | 64        |
| <b>DucoBox Energy Premium</b> .....   | <b>66</b> |
| Duco Energy Premium System 1-zone (no humidity measurement) .....             | 70        |
| Duco Energy Premium System 1-zone (central humidity measurement) .....        | 72        |
| Duco Energy Premium System 1-zone (local humidity measurement) .....          | 74        |
| Duco Energy Premium System 2-zone (no humidity measurement) .....             | 76        |
| Duco Energy Premium System 2-zone (central humidity measurement) .....        | 78        |
| Duco Energy Premium System 2-zone (local humidity measurement) .....          | 80        |

## CONTROL COMPONENTS ..... 82

## AIR DUCT SYSTEM ..... 86

## VENTS ..... 92

## AIR FLOW ..... 96

# MISCELLANEOUS

---

|                         |     |
|-------------------------|-----|
| Part F .....            | 102 |
| Service .....           | 104 |
| Notes .....             | 105 |
| Installation tips ..... | 106 |

### DISCLAIMER

Illustrations in this catalogue may differ from the actual product. Printing errors and/or changes excepted regarding prices and text.  
DUCO reserves the right to amend this information at any time. The statutory information stated may be subject to changes in legislation.  
All prices are recommended prices excluding VAT.

# THE NATURAL FAMILY

Priority to Fresh Air



DucoBox Reno

DucoBox Silent (Connect)

DucoBox Focus

SCAN & DISCOVER



Discover our MEV systems,  
**The Natural Family!**

## Natural supply of fresh air

Our ventilation boxes for natural ventilation (MEV system) combine **comfort and efficiency**. Fresh air flows in naturally through smart grilles in walls or windows and is mechanically extracted in wet rooms, for a **healthy and comfortable indoor climate**.



## Smart zonal control

Our **intelligent demand control based on humidity and CO<sub>2</sub>** ventilates only where and when necessary. This is done fully **automatically**, making the system **quieter** (30% less noise) and **more energy-efficient** (up to 40% savings) compared to traditional ventilation systems. Enjoy a quieter, more economical and healthier indoor climate.

## Ideal for renovation

Our **compact MEV systems** are perfect for **renovations**. They are easy to install in small spaces and meet strict renovation standards. Enjoy **natural supply, easy maintenance and quick installation** with minimal disruption.



# THE ENERGY FAMILY

Priority to Energy Savings



DucoBox Comfort Plus  
D250

DucoBox Comfort Plus  
D350/D450/D550

DucoBox Premium  
D325/D400

## SCAN & DISCOVER



Discover our MVHR systems,  
**The Energy Family!**

## Quiet

The freshest air without distracting background noise? With the DucoBox Energy Comfort Plus and Energy Premium, it becomes a reality, thanks to the excellent **sound-absorbing sleeve** (additional attenuation 10 dB). Our innovative units are equipped with the **quietest fans on the market**, making them virtually silent.



## Smart 2-zone control

All MVHR units are available with smart 2-zone control. A dynamic valve optimally distributes the air flows between two zones based on CO<sub>2</sub> and humidity measurement. The 2-zone control provides **better acoustics and energy savings**. With the DucoBox Energy Premium, internal control offers additional convenience thanks to the plug & play concept: only basic wiring for power supply is required.

## Install in no time

The **automatic calibration** of our units speeds up installation and **saves installers up to 50 % calibration time**, a cost saving of at least 25 pounds! The copy function in the DucoBox Energy Comfort (Plus) and Energy Sky makes it easy to copy settings in serial construction, which saves a lot of time and also money (at least 15 pounds/unit). These units are also **100 % by software L/R exchangeable**.



# WHY DUCO?

## → One-stop-shop for your end-to-end ventilation solution

Complete range of MEV and MVHR ventilation units, air ducts & accessories.

## → Smart demand control

The room is **only ventilated when necessary** and in the correct amount. CO<sub>2</sub> concentration and air humidity are used as indicators. This helps avoiding unnecessary heat loss while guaranteeing an optimal indoor climate.

## → High energy conversion efficiency

The combination of dynamic air distribution filters and **high performance heat exchangers** results in very high efficiency ratios.

## → The quietest systems

A comfortable indoor climate is created by **whisper-quiet ventilation systems**. DUCO excels in acoustics, especially where it matters most: the living areas and bedrooms.

## → Connectivity

The optional Duco Connectivity Board 2.0 offers the possibility of seamless integration with the Duco Installation App and DUCO HOME app for effortless control, while also connecting smoothly with home automation and building management systems via **REST API** or **Modbus TCP**, delivering maximum flexibility and smart connectivity.

## → Automatic calibration

The automatic calibration, whereby the measuring and adjustment technology is based on the principles of calibration under constant pressure, always offers a 100% guarantee of a **qualitative end result** and translates into a 50% saving in set-up time for the installer.

# DUCO introduces **DEMAND-CONTROLLED VENTILATION**

Historically, MVHR-units used to run **continuously**: 24 hours a day, 7 days a week. This was deemed to be "ok" as there was "heat recovery" anyway, and so the energy losses were deemed to be small.

DUCO feels that this "**old school**"-way-of-thinking is a thing of the past and decided to go a step beyond the "normal" operation mode of a "traditional" MVHR system.

So next to offering user control options on the display or via a user controller; next to offering the possibility to make the unit function on a time-schedule, DUCO also offers true "**on demand**" solutions which result in true energetically optimised ventilation-solutions: **only ventilate when necessary, where it is necessary and as long as it is necessary!**



## → How does it work?

Sensors permanently measure the indoor air quality in a room (or centrally, depending on the case): if the indoor air quality (CO<sub>2</sub> or humidity) is found to be OK, the **ventilation is put to a strict minimum** (minimum energy consumption and minimum heat losses).

On the other hand, if the indoor air quality is found to be or become worry-some, the ventilation is triggered immediately in a modular way, i.e. more or less intense according to **intelligent algorithms** (energy is only used when needed to reach healthy indoor air).


With an "**on demand**" DUCO-system, the occupant can always be assured to breathe the best possible indoor air, whilst also using the least amount of energy! **DUCO brings you the SMARTEST ventilation solutions!**

Check out our various control components from page 82 onward.

# UNIQUE AT DUCO

## MEV SYSTEM

Unlike a ventilation system that extracts air from the entire house, including healthy air, the **DucoBox Focus** is a ventilation unit that applies **zonal ventilation**. The internal control valves of the DucoBox Focus extract polluted and/or moist air zonally. This means that you only ventilate where necessary, when necessary and in the right amount, to remove the polluted air as quickly as possible.




- ✓ **100 % automatic**  
Demand-controlled ventilation based on CO<sub>2</sub>, Humidity and temperature.
- ✓ **Optimal indoor climate**  
The Duco Focus System **ventilates only where and when needed, and in the right amount**.
- ✓ **Acoustic comfort**  
The **QUIETEST** and **SMARTEST** ventilation boxes on the market.
- ✓ **Aesthetic & minimalist**  
DucoVent Design: **Aesthetic and functional** aluminium vents.
- ✓ **Highest energy gain**  
Controlled supply and extraction = 100 % controlled ventilation.

# UNIQUE AT DUCO

## MVHR SYSTEM


With the **DucoBox Energy Comfort (Plus)**, **DucoBox Energy Sky** and the **DucoBox Energy Premium** DUCO offers a unique ventilation system where 2-zone control can be realised on the supply.

If the air quality in a specific zone is found to be ok, ventilation in that zone is set to a minimum. **Cost savings for heating, lower consumption and acoustic comfort** are the logical consequences. But always with guaranteed indoor air quality!



Sensors meticulously detect the resident's movements throughout the home. This enables where, when and how much ventilation is required to be determined **automatically**.

By controlling both zones separately with an external valve, the consumption of the EC fans is significantly lower, which translates into lower electricity costs.



- ✓ **Low energy consumption**
- ✓ **The quietest MVHR system in the market!**
- ✓ **Automatic calibration!**

# Discover the magic of zonal ventilation

Bring fresh air into your life,  
at the right time, in the right room




30% less noise



40% energy savings

## MEV SYSTEM

Mechanical extract ventilation




### DucoBox Focus

Up to 11 zones

## MVHR SYSTEM

Mechanical ventilation with heat recovery



### DucoBox Energy Premium

2 zones - day / night

### Multi-zone valve

2 zones - day / night in combination with DucoBox Energy Comfort (Plus) and DucoBox Energy Sky



**START YOUR JOURNEY TO  
ZONAL VENTILATION!**

Discover the magic at [duco.eu/zonal-ventilation](http://duco.eu/zonal-ventilation)



## MEV SYSTEM

The **QUIETEST** and **SMARTEST** MEV system!



DucoBox **Reno**



DucoBox **Silent (Connect)**



DucoBox **Focus**



**Optimal ventilation performance**

Centralized built-in humidity detection



**Multiple room connections**

Equiped with 7 spigots



**Intelligent demand control**

Control valve system based on CO<sub>2</sub> and humidity measurement



**Copy functionnality for serial housing**

Ideal for social housing and student flats



**Carefree night's sleep**

Minimum sound power (< 27 dB(A) in occupied zones)



**Smart zonal control**

Up to 7 zones, expandable to 11 zones with duplicator



**Certified Quality**

SAP/Appendix Q listed and BRE approved



**Easy to install**

User-friendly Installation App with wizard and Part F-compliant report



**Automatic calibration**

Guaranteed flow at each vent

### DucoFlex



With DucoFlex, DUKO offers a **complete air duct system**. If you use this **installation-friendly** air-duct system you will enjoy the **energy-efficient and quiet operation** of the ventilation system.



## MVHR SYSTEM

The **QUIETEST** and **SMARTEST** MVHR system!



### DucoBox Energy Comfort (Plus)



#### A solution for every situation

Flow rate up to 550 m<sup>3</sup>/h (at 200 Pa)

### DucoBox Energy Sky



#### Easy to install

Via head-up display or via the Duco Installation App

### DucoBox Energy Premium



#### Smart 2-zone control

Saving up to 40 % through smart zone control



#### Left/right exchangeable

Exchange between left and right variant is carried out 100 % by software



#### Save time = save money

AUTO calibration, COPY function, 100 % exchangeable via display



#### Quietest MVHR on the market

Enjoy a good night's sleep!



#### Automatic calibration

Calibration at constant pressure saves up to 50 % on the configuration time



#### Priority to energy savings

Smart demand control



#### Automatic calibration

Calibration at constant pressure saves up to 50 % on the configuration time

### DucoFlex



With DucoFlex, DUCO offers a **complete air duct system**. If you use this **installation-friendly** air-duct system you will enjoy the **energy-efficient and quiet operation** of the ventilation system.



# DucoBox Reno

The **NUMBER 1** ventilation box for Social Housing and Flats



## Optimal ventilation performance

Centralized built-in humidity detection




## Copy functionnality for serial housing

Ideal for social housing and student flats



## Certified Quality

SAP/Appendix Q listed and BRE approved



Please refer to page 106 for essential installation tips!

## DucoBox Reno

MEV system

Up to **325 m<sup>3</sup>/h** (90 l/s) at 150 Pa

The DucoBox Reno UK is a Central Mechanical Extract Ventilation (CMEV) system, designed for houses and apartment buildings. With its continuous operation, it ensures **optimal indoor air quality** while delivering exceptional energy efficiency and silent performance.

Whether you are developing social housing projects or modern apartments, the DucoBox Reno UK provides a **reliable, cost-effective solution** for achieving excellent ventilation standards. By integrating cutting-edge technology, this system meets the diverse demands of today's housing market, combining user comfort, sustainability, and straightforward compliance with UK building regulations.

### FEATURES

|  |   |  |
|--|---|--|
| <b>Width x Height x Depth:</b><br>381 x 366 x 204 mm<br><b>Weight:</b> 3,1 kg<br><b>Extraction capacity at 150 Pa:</b><br>325 m <sup>3</sup> /h (90 l/s)<br><b>Power supply:</b> 230 VAC | <b>Energy label:</b> class B in a system with at least two sensors<br><b>Communication:</b><br>RF | <b>Peak power:</b> 47 W<br><b>Air duct connections:</b><br>Extraction areas:<br>4 x Ø 125 mm<br>1 x rear connection<br>Extraction to the outside: 1 x Ø 125 mm |
|--|---|--|

## VENTILATION UNIT



DucoBox Reno (UK)

**0000-4948**

## ALL-IN-ONE KITS

DucoBox Reno

DUCO All-in-one kits include both an extractor fan and associated control components.

All-in-one DucoBox Reno  
Awaab's law

1x DucoBox Reno (UK)  
1x User controller RF / Battery White  
3x DucoVent Basic

**0000-7100**



## CONTROL COMPONENTS DucoBox Reno

DucoBox Reno is equipped with a RH measurement in the scroll as standard.

### → CO<sub>2</sub> BOX SENSOR



The optional CO<sub>2</sub> Box Sensor can be installed very easily and quickly and provides CO<sub>2</sub> measurement in an air duct. The sensor is wired directly to the printed circuit board. This means that no wiring for room sensors needs to be provided. A DucoBox Reno contains a maximum of one box sensor – which can be clicked into a specific duct opening.

|   |                       |                                |
|---|-----------------------|--------------------------------|
| Peak power: < 1 W                       | Stand-by power: < 1 W | Power supply: From the DucoBox |
| CO <sub>2</sub> Box sensor DucoBox Reno |                       | 0000-4743                      |

### → EXTERNAL CONTROL COMPONENTS

The DucoBox Reno can be connected to the following external control components.

|                                      |             |
|--------------------------------------|-------------|
| User controllers & room sensors      | see page 82 |
| Switch sensor (for switch detection) | see page 84 |



## OPTIONS & ACCESSORIES DucoBox Reno



Reducer 160/125

0000-4543

Reducer from Ø 125 mm (DucoBox spigot) to Ø 160 mm (air duct).



Duct flange Ø 125 mm

0000-4728

The duct flange is a handy tool for quickly connecting flexible ducts or silencers to a Ø 125mm spigot of a DucoBox. Thanks to the smart and patented self-clamping 'Push & Go' fastening principle, the installer saves a lot of time when mounting pipes.





Renovation

# Duco Reno System

MEV system | Central ventilation (1 zone) | Up to 325 m<sup>3</sup>/h (90 l/s) at 150 Pa  
With CO<sub>2</sub> Box sensor



CONTROL ON EXTRACTION



## ALL-IN-ONE KIT

- All-in-one DucoBox Reno Awaab's law\*

0000-7100

The bullet next to the item numbers below indicates which and how many components the basic kit contains.

\*UK only

## COMPONENTS



DucoBox Reno (UK)

1 0000-4948

Component on diagram

1

CO<sub>2</sub> Box sensor DucoBox Reno

0000-4743

2



User controller RF / Wired White

0000-4602

3

User controller RF / Battery White

1 0000-4600

CO<sub>2</sub> Room sensor with control RF/Wired White

0000-4604

CO<sub>2</sub> Room sensor without control RF / Wired White

0000-4637

4 | 5 | 6

Humidity Room sensor with control RF / Wired White

0000-4606



Surface-mounted box DUCO controllers / sensors

0000-5009

→ See chapter 'Control components' from page 82 for black control components and more information on all user controllers & room sensors.

7



Switch sensor RF/230 VAC


0000-4174



DucoVent Basic

3 0000-4178

→ See chapter 'Vents' from page 92 for more information on all types of vents.



| Energy label | Extraction | Detection                   | Required components | Optional components |
|--------------|------------|-----------------------------|---------------------|---------------------|
| <b>B</b>     | Central    | High-humidity rooms         | ■                   | ■                   |
| <b>B</b>     | Central    | Damp areas + master bedroom | ■ + ■               | ■                   |
| <b>B</b>     | Central    | Damp rooms + all bedrooms   | ■ + ■ + ■           | ■                   |

→ Extraction of stale air

→ Supply of fresh air



# DucoBox Silent (Connect)

The **QUIETEST** MEV system!



## Multiple room connections

Equiped with 7 spigots



## Carefree night's sleep


Minimum sound power  
( $< 27$  dB(A) in occupied zones)



## Easy to install\*

User-friendly Installation App with  
wizard and Part F-compliant report

\*DucoBox Silent Connect only



Please refer to page 106 for essential installation tips!

## DucoBox Silent (Connect)

MEV system

Up to **400 m<sup>3</sup>/h** (111 l/s) at 150 Pa

The energy-efficient, compact DucoBox Silent provides central extraction of humid and polluted air within DUKO's Demand-Controlled Natural Ventilation Systems. The latest generation\* features a simplified calibration procedure and integrated humidity sensor for easy installation and control. The efficient EC motor guarantees a long service life.

### FEATURES

|  |  |  |
|--|--|--|
| <b>Width x Height x Depth:</b> 480 x 480 x 194 mm<br><b>Weight:</b> 4,3 kg<br><b>Extraction capacity at 150 Pa:</b><br>400 m <sup>3</sup> /h (111 l/s)<br><b>Power supply:</b> 230 VAC<br><b>Energy label:</b> class B in a system with at least two sensors | <b>Communication:</b><br>DucoBox Silent: RF only, not expandable<br>DucoBox Silent Connect: RF and Wired.<br>Expandable with Connectivity Board 2.0 (see 'Options & accessories') for communication with the Duco Installation App and the DUKO HOME app, REST API and Modbus TCP. | <b>Peak power:</b> 84 W<br><b>Air duct connections:</b><br>Extraction areas:<br>7 x Ø 125 mm<br>Extraction to the outside:<br>1 x Ø 125 mm |
|--|--|--|

\*These references do not apply to the Ducobox Silent Connect.

## VENTILATION UNIT



| Type                        | Plug |                                  |
|-----------------------------|------|----------------------------------|
| DucoBox Silent (UK)         | G    | <b>0000-7036</b>                 |
| DucoBox Silent Connect (UK) | G    | Only available in All-in-one kit |

## ALL-IN-ONE KITS DucoBox Silent

DUKO All-in-one kits include both an extractor fan and associated control components.

|  |  |                  |
|--|--|------------------|
| <b>All-in-one DucoBox Silent Connect (UK) + RH</b> | 1 x DucoBox Silent Connect (UK)<br>1 x Humidity Box sensor | <b>0000-4808</b> |
|--|--|------------------|



## CONTROL COMPONENTS

DucoBox Silent (Connect)

---



### → BOX SENSORS

Box sensors can be installed very easily and quickly and provide **CO<sub>2</sub> and/or moisture measurement in an air duct**. They are wired directly to the circuit board. This means that no wiring for room sensors needs to be provided.

A DucoBox Silent Connect contains **a maximum of two box sensors** – one CO<sub>2</sub> Box sensor and/or one Humidity Box Sensor – each of which can be clicked separately into a specific duct opening or together into one duct opening of the DucoBox.

| Peak power: < 1 W          | Stand-by power: < 1 W | Power supply: From the DucoBox |
|----------------------------|-----------------------|--------------------------------|
| CO <sub>2</sub> Box sensor |                       | <b>0000-4216</b>               |
| Humidity Box sensor        |                       | <b>0000-4218</b>               |

### → EXTERNAL CONTROL COMPONENTS

The DucoBox Silent Connect can be connected to the following external control components.

|                                      |             |
|--------------------------------------|-------------|
| User controllers & room sensors      | see page 82 |
| Switch sensor (for switch detection) | see page 84 |



## OPTIONS & ACCESSORIES DucoBox Silent (Connect)



### Silent Plus Kit

**0000-4182**

The Silent Plus Kit provides additional acoustic damping of up to 3 dB(A)! Three composite foam pads per box, placed as close to the extraction as possible, are sufficient.



### Duco Connectivity Board 2.0

**0000-4945**

The optional Duco Connectivity Board 2.0 offers the possibility of application within the DucoBox Silent Connect, DucoBox Focus and DucoBox Energy Comfort (Plus) / Sky / Premium, enabling communication with the Duco Installation App and DUCO HOME app, while also allowing integration into home automation and building management systems via REST API or Modbus TCP.



### Breech Y-piece 2 x 125 to 1 x 160

**0000-4334**

This piece allows a duct of Ø 160 mm to be connected to two spigots of the DucoBox Silent Connect Ø 125 mm). Splitting the flow between two ducts reduces resistance, resulting in quieter and more energy-efficient operation.



### Reducer 160/125

**0000-4543**

Reducer from Ø 125 mm (DucoBox spigot) to Ø 160 mm (air duct).



### EasySwitch

**0000-5134**

This 'universal' plate allows you to replace an outdated ventilation box in a renovation project without cutting and breaking with the DucoBox Silent Connect or Focus. After fitting against the wall, the unit can easily be clicked onto the plate, resulting in vibration-free operation during air extraction.



### Coaxial cable set 8 m

**0000-4418**

The set comprises an 8 m long coaxial cable with pre-fitted connectors at both ends. Using this set, the antenna of the DucoBox Silent Connect, DucoBox Focus or DucoBox Energy devices can be moved, if necessary, to a place where the RF range is optimal.



### Duco Power supply 230VAC-24VDC/20W + casing

**0000-4763**

The Duco Power Supply 230VAC-24VDC/20W is the best solution to power Duco Wired components from a central 230V connection. The component comes with a surface-mounted junction box as standard. The sum of the peak power of all connected DUCO components can be 20W at most when using one Power Supply.



### Flow regulator 15-50 m³/h Ø125

**0000-4836**

### Flow regulator 50-100 m³/h Ø125

**0000-4837**

The adjustable flow regulator is an element that is placed in a duct to obtain a constant flow in a pressure range between 50 and 250 Pascal. It is used for both supply and extraction.



Renovation



NIGHTBOOST



CONTROL ON EXTRACTION

# Duco Silent (Connect) System

MEV system | Central ventilation (1 zone) | Up to 400 m<sup>3</sup>/h (111 l/s) at 150 Pa

## ALL-IN-ONE KIT

|  |   |           |
|--|---|-----------|
|  | All-in-one DucoBox Silent Connect (UK) + RH | 0000-4808 |
|--|---|-----------|

The bullet next to the item numbers below indicates which and how many components the basic kit contains.

## COMPONENTS



|                             |           |                      |
|-----------------------------|-----------|----------------------|
| DucoBox Silent (UK)         | 0000-7036 | 1                    |
| DucoBox Silent Connect (UK) | 0000-4808 | 1 only in All-in-one |



|   |           |   |
|---|-----------|---|
| Silent Plus Kit (3 damping pads + 3 caps) | 0000-4182 | 2 |
|---|-----------|---|



|                            |           |     |
|----------------------------|-----------|-----|
| CO <sub>2</sub> Box sensor | 0000-4216 | 5   |
| Humidity Box sensor        | 0000-4218 | 4 * |

\* The DucoBox Silent comes fully equipped with an integrated humidity sensor as standard, making the RH Box sensor unnecessary.



|   |           |       |
|---|-----------|-------|
| User controller RF /Wired White                             | 0000-4602 | 3     |
| User controller RF /Battery White                           | 0000-4600 |       |
| CO <sub>2</sub> Room sensor with control RF/Wired White     | 0000-4604 |       |
| CO <sub>2</sub> Room sensor without control RF /Wired White | 0000-4637 | 7 8 9 |
| Humidity Room sensor with control RF /Wired White           | 0000-4606 |       |
| Surface-mounted box DUCO controllers / sensors              | 0000-5009 |       |

→ See chapter 'Control components' from page 82 for black control components and more information on all user controllers & room sensors.



|                          |           |   |
|--------------------------|-----------|---|
| Switch sensor RF/230 VAC | 0000-4174 | 6 |
|--------------------------|-----------|---|




|                             |           |  |
|-----------------------------|-----------|--|
| Duco Connectivity Board 2.0 | 0000-4945 |  |
|-----------------------------|-----------|--|



|                                   |           |  |
|-----------------------------------|-----------|--|
| Breech Y-piece 2 x 125 to 1 x 160 | 0000-4334 |  |
|-----------------------------------|-----------|--|

→ See chapter 'Vents' from page 92 for more information on all types of vents.



| Energy label | Extraction | Detection                   | Required components | Optional components |
|--------------|------------|-----------------------------|---------------------|---------------------|
| <b>B</b>     | Central    | High-humidity rooms         | ■                   | ■                   |
| <b>B</b>     | Central    | Damp areas + master bedroom | ■ + ■               | ■                   |
| <b>B</b>     | Central    | Damp rooms + all bedrooms   | ■ + ■ + ■           | ■                   |

→ Extraction of stale air  
 → Supply of fresh air



# DucoBox Focus

The **SMARTEST** MEV system!



## Intelligent demand control

Control valve system based on CO<sub>2</sub> and humidity measurement




## Smart zonal control

Up to 7 zones, expandable to 11 zones with duplicator



## Automatic calibration

Guaranteed flow at each vent



Please refer to page 106 for essential installation tips!

## DucoBox Focus

MEV system

Up to **400 m<sup>3</sup>/h** (111 l/s) at 150 Pa

The DucoBox Focus is an extraction fan that provides **zonal extraction** within DUCO's Demand-Controlled Natural Ventilation Systems. The DucoBox Focus is both the motor of the system, and the master unit to which control components can be paired.

This **quiet, compact, durable** and highly **energy-efficient extractor fan** removes moist and/or polluted air when needed and in the right quantity. Integrated control valves (to be ordered separately) also ensure that **air is exhausted only where necessary**, providing even quieter and more energy-efficient operation. Simple design and an efficient EC motor ensure long service life.

### FEATURES

|  |   |  |
|--|---|--|
| <b>Width x Height x Depth:</b><br>480 x 480 x 194 mm<br><b>Weight:</b> 4,3 kg<br><b>Extraction capacity at 150 Pa:</b><br>400 m <sup>3</sup> /h (111 l/s)<br><b>Power supply:</b> 230 VAC<br><b>Peak power:</b> 84 W | <b>Air duct connections:</b><br>Extraction areas:<br>7 x Ø 125 mm<br>Extraction to the outside<br>1 x Ø 125 mm<br><b>Energy label:</b> class B in a system with at least two sensors, and provided with valve control | <b>Communication:</b><br>RF and Wired. Expandable with Connectivity Board 2.0 (see 'Options & accessories') for communication with the Duco Installation App and the DUCO HOME app, REST API and Modbus TCP. |
|--|---|--|

## VENTILATION UNIT



| Type  | Plug |                  |
|---|------|------------------|
| DucoBox Focus (UK) <small>(control valves not included)</small> | G    | <b>0000-4448</b> |

At least two control valves should always be provided in the DucoBox Focus.

## BASIC KITS DucoBox Focus

DUCO basic kits contain a selection of control components at economical prices.

|  |   |                  |
|--|---|------------------|
| <b>Basic kit</b><br><b>Duco Focus System</b> | 1 x CO <sub>2</sub> Control valve 75 m <sup>3</sup> /h living room / open kitchen<br>1 x Humidity /CO <sub>2</sub> Control valve 50 m <sup>3</sup> /h bathroom + WC<br>1 x CO <sub>2</sub> Control valve 25 m <sup>3</sup> /h toilet<br>1 x User controller RF/Wired White<br>1 x Silent Plus Kit (3 damping pads + 3 caps) | <b>0000-4646</b> |
|--|---|------------------|

|  |   |                  |
|--|---|------------------|
| <b>Basic kit</b><br><b>Duco Focus System</b><br><b>with extraction in the bedroom(s)</b> | 1 x CO <sub>2</sub> Control valve 75 m <sup>3</sup> /h living room / open kitchen<br>1 x Humidity /CO <sub>2</sub> Control valve 50 m <sup>3</sup> /h bathroom + WC<br>2 x CO <sub>2</sub> Control valve 30 m <sup>3</sup> /h bedroom(s)<br>1 x CO <sub>2</sub> Control valve 25 m <sup>3</sup> /h toilet<br>1 x User controller RF/Wired White | <b>0000-4645</b> |
|--|---|------------------|



## CONTROL COMPONENTS

### DucoBox Focus



#### → CONTROL VALVES

The control valves, optionally equipped with a sensor for **CO<sub>2</sub> or moisture measurement**, can be integrated **into the extractor fan**. These valves ensure that only polluted and/or humid air is exhausted, where and when needed and in the right quantity.

The default set flow rate of the control valves can be manually changed during or after installation via the display menu, the Duco Installer Service Tool or Duco Installation App.

|   |  |                                |
|---|--|--------------------------------|
| Width x Height x Depth: 141 x 167 x 46.5 mm<br>Weight: 0.220 kg | Peak power: 2.04 W<br>Standby power: 0.24W | Power supply: From the DucoBox |
|---|--|--------------------------------|

#### For CO<sub>2</sub>-controlled living areas

A CO<sub>2</sub> Control valve commands the ventilation system based on continuous measurement of both CO<sub>2</sub> (indoor climate indicator) and temperature.

|   |           |
|---|-----------|
| CO <sub>2</sub> Control valve 75 m <sup>3</sup> /h living room / open kitchen | 0000-4163 |
| CO <sub>2</sub> Control valve 30 m <sup>3</sup> /h bedroom(s)                 | 0000-4164 |

#### For toilet

Based on CO<sub>2</sub> measurement, this valve detects **presence** in a toilet, after which the ventilation system will extract the polluted air. Note: a CO<sub>2</sub> Control Valve for toilet works in a different mode than for living room / open kitchen / bedroom. This is necessary for correct operation of the system.

|   |           |
|---|-----------|
| CO <sub>2</sub> Control valve 25 m <sup>3</sup> /h toilet | 0000-4208 |
|---|-----------|

#### For sanitary / damp areas (+ WC)

The Humidity Control valve commands the ventilation system based on continuous measurement of relative **humidity** (RH) and temperature. With the Control valve for bathrooms with WC, presence in the toilet is detected based on CO<sub>2</sub> measurement.

|   |           |
|---|-----------|
| Humidity Control valve 50 m <sup>3</sup> /h bathroom/ laundry room        | 0000-4162 |
| Moisture/CO <sub>2</sub> Control valve 50 m <sup>3</sup> /h bathroom + WC | 0000-4644 |

#### Various applications

For efficient extraction in areas such as a storage room, you can also opt for a Sensorless Control valve. This control valve can be combined with control components in the room, such as a switch sensor or room sensor.

|  |           |
|--|-----------|
| Sensorless Control valve 25 m <sup>3</sup> /h various applications | 0000-4165 |
|--|-----------|

#### → EXTERNAL CONTROL COMPONENTS

The DucoBox Focus can be paired with the following external control components.

|                                      |             |
|--------------------------------------|-------------|
| User controllers & room sensors      | see page 82 |
| Switch sensor (for switch detection) | see page 84 |



## OPTIONS & ACCESSORIES DucoBox Focus



### Silent Plus Kit

0000-4182

The Silent Plus Kit provides additional acoustic damping of up to 3 dB(A)! Three composite foam pads per box, placed as close to the extraction as possible, are sufficient.



### Duco Connectivity Board 2.0

0000-4945

The optional Duco Connectivity Board 2.0 offers the possibility of application within the DucoBox Silent Connect, DucoBox Focus and DucoBox Energy Comfort (Plus) / Sky / Premium, enabling communication with the Duco Installation App and DUCO HOME app, while also allowing integration into home automation and building management systems via REST API or Modbus TCP.



### Reducer 160/125

0000-4543

Reducer from Ø 125 mm (DucoBox spigot) to Ø 160 mm (air duct).



### EasySwitch

0000-5134

This 'universal' plate allows you to replace an outdated ventilation box in a renovation project without drilling or channelling with the DucoBox Silent Connect or Focus. After fitting against the wall, the unit can easily be clicked onto the plate, resulting in vibration-free operation during air extraction.



### Coaxial cable set 8 m

0000-4418

The set comprises an 8 m long coaxial cable with pre-fitted connectors at both ends. Using this set, the antenna of the DucoBox Silent Connect, DucoBox Focus or DucoBox Energy devices can be moved, if necessary, to a place where the RF range is optimal.



### Duco Power supply 230VAC-24VDC/20W + casing

0000-4763


The Duco Power Supply 230VAC-24VDC/20W is the best solution to power Duco Wired components from a central 230V connection. The component comes with a surface-mounted junction box as standard. The sum of the peak power of all connected DUCO components can be 20W at most when using one Power Supply.



### Duplicator control valves

0000-4454

The Duplicator control valves offers the possibility of duplicating spigots on the DucoBox Focus. This allows a zonal ventilation system to be built up with up to 11 connections (of which a maximum of 7 connections with a CO<sub>2</sub> control valve). The connector supplied allows the wiring of these control valves to be easily looped through to the DucoBox Focus. And this, as always within DUCO systems, invisible and behind the lid!





Renovation



NIGHTBOOST



CONTROL ON EXTRACTION

# Duco Focus System

MEV system | Local ventilation | Up to 400 m<sup>3</sup>/h (111 l/s) at 150 Pa

## BASIC KIT


|  |  |           |
|--|--|-----------|
|  | Basic kit<br>Duco Focus System                                   | 0000-4646 |
|  | Basic kit Duco Focus System<br>with extraction in the bedroom(s) | 0000-4645 |

The bullet next to the item numbers below indicates which and how many components the basic kit contains.

## COMPONENTS

|  |   | Component on diagram |
|--|---|----------------------|
|  | DucoBox Focus (UK)  | 0000-4448            |
|  | Silent Plus Kit (3 damping pads + 3 caps)   | 0000-4182            |
|  | CO <sub>2</sub> Control valve 75 m <sup>3</sup> /h (living room / open kitchen)   | 0000-4163            |
|  | CO <sub>2</sub> Control valve 30 m <sup>3</sup> /h (bedroom(s))   | 0000-4164            |
|  | CO <sub>2</sub> Control valve 25 m <sup>3</sup> /h (toilet)   | 0000-4208            |
|  | Humidity Control valve 50 m <sup>3</sup> /h (bathroom / laundry room)   | 0000-4162            |
|  | CO <sub>2</sub> /Humidity Control valve 50 m <sup>3</sup> /h (bathroom + WC)  | 0000-4644            |
|  | Sensorless Control valve 25 m <sup>3</sup> /h (various applications)  | 0000-4165            |
|  | Duplicator control valves   | 0000-4454            |
|  | User controller RF / Wired White  | 0000-4602            |
|  | User controller RF / Battery White  | 0000-4600            |
|  | CO <sub>2</sub> Room sensor with control RF/Wired White   | 0000-4604            |
|  | CO <sub>2</sub> Room sensor without control RF / Wired White  | 0000-4637            |
|  | Humidity Room sensor with control RF / Wired White  | 0000-4606            |
|  | Surface-mounted box DUCO controllers / sensors  | 0000-5009            |
|  | → See chapter 'Control components' from page 82 for black control components and more information on all user controllers & room sensors. |                      |
|  | Switch sensor RF/230 VAC  | 0000-4174            |
|  | Duco Connectivity Board 2.0   | 0000-4945            |

→ See chapter 'Vents' from page 92 for more information on all types of vents.



| Energy label | Extraction | Detection             | Required components | Optional components |
|--------------|------------|-----------------------|---------------------|---------------------|
| <b>B</b>     | Local      | High-humidity rooms   | ■                   | ■                   |
| <b>B</b>     | Local      | Damp rooms + bedrooms | ■ + ■               | ■                   |

→ Extraction of stale air

→ Supply of fresh air



# DucoBox Energy Comfort (Plus)

The **SMARTEST** MVHR system!



Plus D250

D325

D400

Plus D350  
Plus D450  
Plus D550



## A solution for every situation

Flow rate up to 550 m<sup>3</sup>/h  
(at 200 Pa)



## Left/right exchangeable

Exchange between left and right variant is carried out 100% by software



## Automatic calibration

Calibration at constant pressure saves up to 50% on the configuration time



Please refer to page 107 for essential installation tips!

# DucoBox Energy Comfort (Plus)

MVHR

Up to **550 m<sup>3</sup>/h** (153 l/s) at 200 Pa

The DucoBox Energy Comfort is a compact and light **mechanical ventilation unit with heat recovery**. With a capacity of up to 400 m<sup>3</sup>/h, this is the basic ventilation solution for apartments and serial housing construction. In addition, the D325 variant weighs only 21 kg. In other words: easy **to install by one person**.

DucoBox Energy Comfort Plus was developed with the aim of guaranteeing an even **quieter operation** and to be able to offer **higher flow rates** (up to 550 m<sup>3</sup>/h).

Within the DucoBox Energy Comfort (Plus) range, the left/right exchange is 100% software-driven thanks to the **patented principle of the double by-pass**.

The demand control of the DucoBox Energy Comfort (Plus) results in **intelligent and energy-efficient operation**. Together with the smart demand control based on CO<sub>2</sub> and humidity, the dynamic air distribution filters ensure **exceptional efficiency** within this compact unit.

The compact and quick-to-install 2-zone valves provide the most energy-efficient result that can be achieved with an MVHR system. Please note that the **zone control** reduces the noise considerably! Comfort guaranteed!

## FEATURES

| General features  | Comfort D250 / Plus D250  | Comfort D400   |
|---|---|--|
| <b>Connection type</b><br>1 x extraction to outside (EHA)<br>1 x supply from outside (ODA)<br>1 x extraction from inside (ETA)<br>1 x supply to inside (SUP)  | <b>Width x Height x Depth:</b><br>D250: 560 x 669 x 491 mm<br>Plus D250: 565 x 669 x 491 mm<br><b>Weight:</b> to be measured<br><b>Flow rate / pressure:</b><br>250 m <sup>3</sup> /h (69 l/s) / 150 Pa<br><b>Number of air ducts:</b> 4 x Ø 125<br><b>Peak power:</b> to be measured | <b>Width x Height x Depth:</b> 756 x 800 x 584 mm<br><b>Weight:</b> 31 kg<br><b>Flow rate / pressure:</b><br>400 m <sup>3</sup> /h (111 l/s) / 200 Pa<br><b>Number of air ducts:</b> 4 x Ø 180<br><b>Peak power:</b> 2 x 72,5 W  |
| <b>Energy label:</b> A+<br><b>Communication:</b><br>RF and Wired. Expandable with Connectivity Board 2.0 (see 'Options & accessories') for communication with the Duco Installation App and the DUCO HOME app, REST API and Modbus TCP. | <b>Comfort D325</b><br><b>Width x Height x Depth:</b> 700 x 705 x 525 mm<br><b>Weight:</b> 21 kg<br><b>Flow rate / pressure:</b><br>325 m <sup>3</sup> /h (90 l/s) / 150 Pa<br><b>Number of air ducts:</b> 4 x Ø 160<br><b>Peak power:</b> 2 x 59 W                                   | <b>Comfort Plus D350 / D450 / D550</b><br><b>Width x Height x Depth:</b> 760 x 803 x 584 mm<br><b>Weight:</b> 47 kg<br><b>Flow rate / pressure:</b><br>D350: 350 m <sup>3</sup> /h (97 l/s) / 200 Pa<br>D450: 450 m <sup>3</sup> /h (125 l/s) / 200 Pa<br>D550: 550 m <sup>3</sup> /h (153 l/s) / 200 Pa<br><b>Number of air ducts:</b> 4 x Ø 180<br><b>Max. power per motor:</b><br>D350: approx. 59 W<br>D450: approx. 98 W<br>D550: approx. 135 W |

## VENTILATION UNIT



| Type of DucoBox   | Passive House Certified Component | Plug |                  |
|---|-----------------------------------|------|------------------|
| DucoBox Energy Comfort D250 (UK)<br><b>available Q1/2026</b>      | ×                                 |      | <b>0000-7075</b> |
| DucoBox Energy Comfort D325 (UK)                                  | ×                                 |      | <b>0000-4658</b> |
| DucoBox Energy Comfort D400 (UK)                                  | ×                                 |      | <b>0000-4757</b> |
| DucoBox Energy Comfort Plus D250 (UK)<br><b>available Q1/2026</b> | ×                                 |      | <b>0000-7079</b> |
| DucoBox Energy Comfort Plus D350 (UK)                             |                                   |      | <b>0000-4758</b> |
| DucoBox Energy Comfort Plus D450 (UK)                             |                                   |      | <b>0000-4759</b> |
| DucoBox Energy Comfort Plus D550 (UK)                             | ×                                 |      | <b>0000-4923</b> |



## CONTROL COMPONENTS

 DucoBox Energy Comfort (Plus)

### → HUMIDITY SENSOR

This sensor is placed **in the extract air duct (ETA)** of the DucoBox Energy Comfort (Plus) and centrally measures the **humidity** of the air extracted from the house. **A maximum of one Humidity Sensor (ETA) per unit.**

|                   |                                   |                                |
|-------------------|-----------------------------------|--------------------------------|
| Peak power: < 1 W | Communication: via supplied cable | Power supply: From the DucoBox |
|-------------------|-----------------------------------|--------------------------------|



Humidity Sensor DucoBox Energy Comfort (Plus) / Sky

**0000-4723**

The Humidity Sensor is installed in a borehole ( $\varnothing$  10mm) in an extraction duct with diameter of your choice.

### → EXTERNAL 2-ZONE

The 2-zone control for the supply to the home is done quickly and discreetly by the compact multi-zone valves. A valve is provided for each branch to the various zones.



|                 |  |  |
|-----------------|--|--|
| Peak power: 7 W | Communication: Wired connection to DucoBox | Power supply: 24 VDC (to be provided externally) |
|-----------------|--|--|

Multi-zone valve DucoBox Energy (Sensorless) Ø125

**0000-4761**

Multi-zone valve DucoBox Energy (Sensorless) Ø160

**0000-4760**

The Duco Branch piece ( $\varnothing$ 180  $\rightarrow$  2x  $\varnothing$ 160) has been developed to allow multi-zone valves to be quickly fitted to DucoBox Energy Comfort (Plus) / Sky. Thanks to the well-thought-out design, the pressure build-up is evenly distributed over both zones. This improves the acoustics of the overall system! By using the connection pieces with joint, the Branch piece can be fitted to any type of DUCO ventilation system. The multi-zone valves D160 can also be mounted airtight without additional material. Save time = save money!

|   |                  |
|---|------------------|
| Duco Branch piece ( $\varnothing$ 180 $\rightarrow$ 2x $\varnothing$ 160) for Multi-zone valves | <b>0000-4995</b> |
|---|------------------|

### → EXTERNAL CONTROL COMPONENTS

The DucoBox Energy Comfort (Plus) can be linked with the following external control components.

|                                      |             |
|--------------------------------------|-------------|
| User controllers & room sensors      | see page 82 |
| Switch sensor (for switch detection) | see page 84 |

### → BASIC KITS

**Basic kit Multizone D160**  
DucoBox Energy Comfort (Plus) / Sky White

2 x Multi-zone valve DucoBox Energy (Sensorless) Ø160  
1 x CO<sub>2</sub> Room sensor with control **RF/Wired White**  
1 x CO<sub>2</sub> Room sensor without control **RF/Wired White**  
1 x Duco Power supply 230VAC-24VDC/20W + casing

**0000-4900**



## OPTIONS & ACCESSORIES DucoBox Energy Comfort (Plus)



|  |                  |
|--|------------------|
| Mounting Chair Standing (Energy Comfort (Plus) D250) | <b>0000-7134</b> |
| <b>available Q2/2026</b>                             |                  |

|   |                  |
|---|------------------|
| Mounting Chair Standing (Energy Comfort D325) | <b>0000-4546</b> |
|---|------------------|

|  |                  |
|--|------------------|
| Mounting chair Standing (Energy Comfort D400/Plus/Premium) | <b>0000-4740</b> |
|--|------------------|

In situations where wall mounting of the DucoBox Energy Comfort (Plus) is not possible, this support frame enables floor mounting. Use of a flat siphon is required.

Width x Height x Depth (incl. DucoBox Energy Comfort D325): 700 x 828 x 525 mm

Width x Height x Depth (incl. DucoBox Energy Comfort D400): 700 x 933 x 525 mm

Width x Height x Depth (incl. DucoBox Energy Comfort Plus): 700 x 936 x 525 mm



|                      |                  |
|----------------------|------------------|
| Siphon flat (Energy) | <b>0000-4376</b> |
|----------------------|------------------|

This flat diaphragm siphon with a height of 64 mm saves space and has less of a risk of air leaks. The siphon can be installed 'dry' and does not dry out on warm days.



|   |                  |
|---|------------------|
| Filterset 2 x Coarse 65% (Energy Comfort (Plus) D250) | <b>0000-7132</b> |
| <b>available Q1/2026</b>                              |                  |

|  |                  |
|--|------------------|
| Filterset Coarse 65% / ePM1 55% (Energy Comfort (Plus) D250) | <b>0000-7133</b> |
| <b>available Q1/2026</b>                                     |                  |

|  |                  |
|--|------------------|
| Filter set 2 x Coarse 65% (Energy Comfort) | <b>0000-4547</b> |
|--|------------------|

|  |                  |
|--|------------------|
| Filter set Coarse 65% / ePM1 55% (Energy Comfort D325) | <b>0000-4661</b> |
|--|------------------|

|  |                  |
|--|------------------|
| Filter set 2 x Coarse 65% (Energy Comfort D400 / Comfort Plus) | <b>0000-4741</b> |
|--|------------------|

|   |                  |
|---|------------------|
| Filter set Coarse 65% / ePM1 55% (Energy Comfort D400 / Comfort Plus) | <b>0000-4742</b> |
|---|------------------|

The filter sets for the DucoBox Energy Comfort (Plus) include the following filters: For supply air (SUP): choice between Coarse 65% ( $\approx$  G4) or ePM1 55% filter ( $\approx$  F7). The ePM1 55% filter lets fewer fine particles through, which has a positive influence on air quality (e.g. for people who have allergies). For extract air (ETA): Coarse 65% filter ( $\approx$  G4)



|                       |                  |
|-----------------------|------------------|
| Coaxial cable set 8 m | <b>0000-4418</b> |
|-----------------------|------------------|

The set comprises an 8 m long coaxial cable with pre-fitted connectors at both ends. This set can be used to relocate the DucoBox Silent Connect, DucoBox Focus or DucoBox Energy Comfort (Plus) / Sky / Premium antenna, if necessary, to a spot where the RF range is optimal.



## Duco Connectivity Board 2.0

**0000-4945**

The optional Duco Connectivity Board 2.0 offers the possibility of application within the DucoBox Silent Connect, DucoBox Focus and DucoBox Energy Comfort (Plus) / Sky / Premium, enabling communication with the Duco Installation App and DUCO HOME app, while also allowing integration into home automation and building management systems via REST API or Modbus TCP.

## Connection piece with joint D125/D125 (M/M)

**0000-7086****available Q2/2026**

## Connection piece with joint D160/D125 (M/M)

**0000-7087****available Q2/2026**

## Connection piece with joint D160/D160 (M/M)

**0000-4724**

## Connection piece with joint D180/D160 (M/M)

**0000-4725**

## Connection piece with joint D180/D180 (M/M)

**0000-4726**

## Connection piece with joint D200/D180 (M/M)

**0000-4727**

## Connection piece 45° with joint D160/D160 (M/M)

**0000-4949**

The connection pieces with joint are used to make a quick and good connection between ducts (extraction and/or supply) or between a duct and a DucoBox. Thanks to the pre-fitted rubber seal, an airtightness class of up to D can be guaranteed at the connection!



## Insulated connection piece with joint D125/D125 (M/M)

**0000-7135****available Q2/2026**

## Insulated connection piece with joint D160/D125 (M/M)

**0000-7136****available Q2/2026**

## Insulated connection piece with joint D160/D160 (M/M)

**0000-7039**

## Insulated connection piece with joint D180/D160 (M/M)

**0000-7040**

## Insulated connection piece with joint D180/D180 (M/M)

**0000-7041**

## Insulated connection piece with joint D200/D180 (M/M)

**0000-7042**

## Insulated connection piece 45° with joint D160/D160 (M/M)

**0000-7043**

The connection pieces with joint are used to make a quick and good connection between ducts (extraction and/or supply) or between a duct and a DucoBox. Thanks to the pre-fitted rubber seal, an airtightness class of up to D can be guaranteed at the connection!



Pre-Heater DucoBox Energy Comfort (Plus) / Sky (UK) **1150 W**  
**available Q2/2026**

**0000-7003**


Pre-Heater DucoBox Energy Comfort (Plus) (UK) **1425W**

**0000-4825**

The Pre-heater is a frost protection based on an electrical resistance of up to 1150W or 1425W that can optionally be applied in the ODA connection of DucoBox Energy Comfort (Plus) and DucoBox Energy Sky. The resistance is modulatively controlled based on various temperature readings in the ventilation unit.

The heater is attached between the unit and the air duct via connectors. The connectors depend on the type of unit and the flow rate. Refer to the table below for the right combination.

| Type of unit                                | Flow rate                             | 1 Connector                   | 2 Heater  | 3 Connector                   |
|---|---------------------------------------|-------------------------------|---|-------------------------------|
| D250  | Up to 250 m <sup>3</sup> /h (69 l/s)  | D160/D125<br><b>0000-7036</b> |   | D160/D125<br><b>0000-7136</b> |
| D325  | Up to 250 m <sup>3</sup> /h (69 l/s)  | D160/D160<br><b>0000-7039</b> | Pre-Heater<br><b>1150 W</b><br><b>0000-7003</b> | D160/D160<br><b>0000-7139</b> |
|   | Up to 325 m <sup>3</sup> /h (90 l/s)  | D180/D160<br><b>0000-7040</b> |   | D160/D160<br><b>0000-7039</b> |
| D400<br>Plus D350<br>Plus D450<br>Plus D550 | Up to 250 m <sup>3</sup> /h (69 l/s)  | D160/D160<br><b>0000-7039</b> | Pre-Heater<br><b>1150 W</b><br><b>0000-7003</b> | D180/D160<br><b>0000-7040</b> |
|   | Up to 325 m <sup>3</sup> /h (90 l/s)  | D180/D160<br><b>0000-7040</b> |   | D180/D160<br><b>0000-7040</b> |
|   | Up to 350 m <sup>3</sup> /h (97 l/s)  | D180/D180<br><b>0000-7041</b> | Pre-Heater<br><b>1450 W</b><br><b>0000-4825</b> | D180/D180<br><b>0000-7041</b> |
|   | Up to 550 m <sup>3</sup> /h (153 l/s) | D180/D200<br><b>0000-7042</b> |   | D180/D180<br><b>0000-7041</b> |



Duco Power supply 230VAC-24VDC/20W + casing

**0000-4763**

The Duco Power Supply 230VAC-24VDC/20W is the best solution to power Duco Wired components from a central 230V connection. The component comes with a surface-mounted junction box as standard. The sum of the peak power of all connected DUCO components can be 20W at most when using one Power Supply.



Flow regulator 15-50 m<sup>3</sup>/h Ø80

**0000-4722**

Flow regulator 15-50 m<sup>3</sup>/h Ø125

**0000-4836**

Flow regulator 50-100 m<sup>3</sup>/h Ø125

**0000-4837**

The adjustable flow regulator is an element that is placed in a duct to obtain a constant flow in a pressure range between 70 and 250 Pascal. It is used for both supply and extraction.



NO humidity measurement


1-ZONE  
SYSTEM

## COMPONENTS

| Component on diagram |
|----------------------|
| 1                    |
| 2                    |
| 3 4 5                |
| 6                    |
| 7                    |

→ See chapter 'Control components' from page 82 for more information on all user controllers &amp; room sensors.

\* Passive House Institute certificate only for DucoBox Energy Comfort Plus D350/D450 units with pre-heater and a maximum flow rate between: 160 m<sup>3</sup>/h and 238 m<sup>3</sup>/h for the D350 variant and 155 m<sup>3</sup>/h and 308 m<sup>3</sup>/h for the D450 variant.



| Detection |                 | Required components | Optional components |
|-----------|-----------------|---------------------|---------------------|
| Humidity  | CO <sub>2</sub> |                     |                     |
| ✗         | ✗               |                     |                     |
| ✗         | Main rooms      | ■                   | ■                   |
| ✗         | All rooms       | ■ + ■               | ■                   |

→ Extraction of stale air  
 → Supply of fresh air

The illustration shows a right-hand variant of the DucoBox Energy Comfort (Plus).



**CENTRAL**  
humidity  
measurement



# Duco Energy Comfort (Plus) System

MVHR | Central ventilation (1-zone) | Up to 550 m<sup>3</sup>/h (153 l/s) at 200 Pa




## COMPONENTS

| Component on diagram |  |
|----------------------|--|
|                      | DucoBox Energy Comfort D250<br>available Q1/2026                               |
| 1                    | DucoBox Energy Comfort D325 (UK)   |
| 1                    | DucoBox Energy Comfort D400 (UK)   |
| 1                    | DucoBox Energy Comfort Plus D250<br>available Q1/2026                          |
| 1                    | DucoBox Energy Comfort Plus D350 (UK)  |
| 1                    | DucoBox Energy Comfort Plus D450 (UK)  |
| 1                    | DucoBox Energy Comfort Plus D550 (UK)  |
| 7                    | Humidity Sensor DucoBox Energy Comfort (Plus) / Sky                            |
| 2                    | User controller RF / Wired White   |
| 2                    | User controller RF / Battery White   |
| 6                    | CO <sub>2</sub> Room sensor with control RF/Wired White                        |
| 3   4   5            | CO <sub>2</sub> Room sensor without control RF/Wired White                     |
| 3   4   5            | Surface-mounted box DUCO controllers / sensors                                 |
| 8                    | Switch sensor RF/230 VAC   |
|                      | Duco Connectivity Board 2.0  |
|                      | Pre-Heater DucoBox Energy Comfort (Plus) / Sky (UK) 1150W<br>available Q2/2026 |
|                      | Pre-Heater DucoBox Energy Comfort (Plus) (UK) 1425W                            |

→ See chapter 'Control components' from page 82 for black control components and more information on all user controllers & room sensors.

→ See chapter 'Vents' from page 92 for more information on all types of vents.

\* Passive House Institute certificate only for DucoBox Energy Comfort Plus D350/D450 units with pre-heater and a maximum flow rate between: 160 m<sup>3</sup>/h and 238 m<sup>3</sup>/h for the D350 variant and 155 m<sup>3</sup>/h and 308 m<sup>3</sup>/h for the D450 variant.



| Detection |                 | Required components | Optional components |
|-----------|-----------------|---------------------|---------------------|
| Humidity  | CO <sub>2</sub> |                     |                     |
| Central   | ×               |                     |                     |
| Central   | Main rooms      | ■ + ■               | ■                   |
| Central   | All rooms       | ■ + ■ + ■ + ■       | ■                   |

→ Extraction of stale air  
→ Supply of fresh air

The illustration shows a right-hand variant of the DucoBox Energy Comfort (Plus).



LOCAL  
humidity  
measurement

1-ZONE  
SYSTEM




## COMPONENTS

| Component on diagram |   |
|----------------------|---|
|                      | DucoBox Energy Comfort D250<br>available Q1/2026 <b>0000-7075</b>   |
| 1                    | DucoBox Energy Comfort D325 (UK) <b>0000-4658</b>   |
|                      | DucoBox Energy Comfort D400 (UK) <b>0000-4757</b>   |
|                      | DucoBox Energy Comfort Plus D250<br>available Q1/2026 <b>0000-7079</b>  |
|                      | DucoBox Energy Comfort Plus D350 (UK) <b>0000-4758</b>  |
|                      | DucoBox Energy Comfort Plus D450 (UK) <b>0000-4759</b>  |
|                      | DucoBox Energy Comfort Plus D550 (UK) <b>0000-4923</b>  |
|                      | User controller RF / Wired White <b>0000-4602</b>   |
|                      | User controller RF / Battery White <b>0000-4600</b>   |
| 5                    | CO <sub>2</sub> Room sensor with control RF/Wired White <b>0000-4604</b>  |
| 2 3 4                | CO <sub>2</sub> Room sensor without control RF / Wired White <b>0000-4637</b>   |
| 6 7                  | Humidity Room sensor with control RF / Wired White <b>0000-4606</b>   |
|                      | Surface-mounted box DUCO controllers / sensors <b>0000-5009</b>   |
|                      | → See chapter 'Control components' from page 82 for black control components and more information on all user controllers & room sensors. |
| 8                    | Switch sensor RF/230 VAC <b>0000-4174</b>   |
|                      | Duco Connectivity Board 2.0 <b>0000-4945</b>  |
|                      | Pre-Heater DucoBox Energy Comfort (Plus) / Sky (UK) 1150W<br>available Q2/2026 <b>0000-7003</b>   |
|                      | Pre-Heater DucoBox Energy Comfort (Plus) (UK) 1425W <b>0000-4825</b>  |

→ See chapter 'Vents' from page 92 for more information on all types of vents.

\* Passive House Institute certificate only for DucoBox Energy Comfort Plus D350/D450 units with pre-heater and a maximum flow rate between: 160 m<sup>3</sup>/h and 238 m<sup>3</sup>/h for the D350 variant and 155 m<sup>3</sup>/h and 308 m<sup>3</sup>/h for the D450 variant.



| Detection |                 | Required components | Optional components |
|-----------|-----------------|---------------------|---------------------|
| Humidity  | CO <sub>2</sub> |                     |                     |
| Local     | ×               | ■ + ■               | ■                   |
| Local     | Main rooms      | ■ + ■ + ■           | ■                   |
| Local     | All rooms       | ■ + ■ + ■ + ■       | ■                   |

The illustration shows a right-hand variant of the DucoBox Energy Comfort (Plus).

→ Extraction of stale air  
 → Supply of fresh air



NO humidity measurement



## BASIC KIT

|  |   |           |
|--|---|-----------|
|  | Basic kit Multizone D160<br>DucoBox Energy Comfort (Plus) / Sky White | 0000-4900 |
|--|---|-----------|


The bullet next to the item numbers below indicates which and how many components the basic kit contains.

## COMPONENTS

| Component on diagram |   |
|----------------------|---|
|                      | DucoBox Energy Comfort D250<br><b>available Q1/2026</b>   |
| 1                    | DucoBox Energy Comfort D325 (UK)  |
| 1                    | DucoBox Energy Comfort D400 (UK)  |
| 1                    | DucoBox Energy Comfort Plus D250<br><b>available Q1/2026</b>  |
| 3 4                  | Multi-zone valve DucoBox Energy (Sensorless) Ø125   |
| 3 4                  | Multi-zone valve DucoBox Energy (Sensorless) Ø160   |
| 3 4                  | Duco Branch piece (Ø180 → 2x Ø160)<br>for Multi-zone valves   |
| 2                    | User controller RF / Wired White  |
| 2                    | User controller RF / Battery White  |
| 8                    | CO <sub>2</sub> Room sensor with control RF/Wired White   |
| 5 6 7                | CO <sub>2</sub> Room sensor without control RF / Wired White  |
| 5 6 7                | Surface-mounted box DUCO controllers / sensors  |
| 9                    | Switch sensor RF/230 VAC  |
|                      | → See chapter 'Control components' from page 82 for black control components and more information on all user controllers & room sensors. |
|                      | Duco Connectivity Board 2.0   |
|                      | Pre-Heater DucoBox Energy Comfort (Plus) / Sky (UK) 1150W<br><b>available Q2/2026</b>   |
|                      | Pre-Heater DucoBox Energy Comfort (Plus) (UK) 1425W   |
|                      | Duco Power supply 230VAC-24VDC/20W + casing   |

→ See chapter 'Vents' from page 92 for more information on all types of vents.

\* Passive House Institute certificate only for DucoBox Energy Comfort Plus D350/D450 units with pre-heater and a maximum flow rate between: 160 m<sup>3</sup>/h and 238 m<sup>3</sup>/h for the D350 variant and 155 m<sup>3</sup>/h and 308 m<sup>3</sup>/h for the D450 variant.



| Detection |                 | Required components | Optional components |
|-----------|-----------------|---------------------|---------------------|
| Humidity  | CO <sub>2</sub> |                     |                     |
| ×         | Main rooms      |                     |                     |
| ×         | All rooms       | ■ + ■               | ■                   |

→ Extraction of stale air

→ Supply of fresh air

The illustration shows a right-hand variant of the DucoBox Energy Comfort (Plus).



**CENTRAL**  
humidity  
measurement



# Duco Energy Comfort (Plus) System

MVHR | Zonal ventilation (2-zone) | Up to 550 m<sup>3</sup>/h (153 l/s) at 200 Pa



## BASIC KIT

|  |   |           |
|--|---|-----------|
|  | Basic kit Multizone D160<br>DucoBox Energy Comfort (Plus) / Sky White | 0000-4900 |
|--|---|-----------|


The bullet next to the item numbers below indicates which and how many components the basic kit contains.

## COMPONENTS

| Component on diagram |   |
|----------------------|---|
|                      | DucoBox Energy Comfort D250<br><b>available Q1/2026</b>                               |
| 1                    | DucoBox Energy Comfort D325 (UK)  |
| 1                    | DucoBox Energy Comfort D400 (UK)  |
| 1                    | DucoBox Energy Comfort Plus D250<br><b>available Q1/2026</b>                          |
| 4                    | Multi-zone valve DucoBox Energy (Sensorless) Ø125                                     |
| 5                    | Multi-zone valve DucoBox Energy (Sensorless) Ø160                                     |
| 5                    | Duco Branch piece (Ø180 → 2x Ø160)<br>for Multi-zone valves                           |
| 3                    | Humidity Sensor DucoBox Energy Comfort (Plus) / Sky                                   |
| 2                    | User controller RF / Wired White  |
| 2                    | User controller RF / Battery White  |
| 9                    | CO <sub>2</sub> Room sensor with control RF/Wired White                               |
| 9                    | CO <sub>2</sub> Room sensor without control RF / Wired White                          |
| 6                    | Surface-mounted box DUCO controllers / sensors  |
| 7                    |   |
| 8                    |   |
| 10                   | Switch sensor RF/230 VAC  |
|                      | Duco Connectivity Board 2.0   |
|                      | Pre-Heater DucoBox Energy Comfort (Plus) / Sky (UK) 1150W<br><b>available Q2/2026</b> |
|                      | Pre-Heater DucoBox Energy Comfort (Plus) (UK) 1425W                                   |
|                      | Duco Power supply 230VAC-24VDC/20W + casing   |

→ See chapter 'Vents' from page 92 for more information on all types of vents.


\* Passive House Institute certificate only for DucoBox Energy Comfort Plus D350/D450 units with pre-heater and a maximum flow rate between: 160 m<sup>3</sup>/h and 238 m<sup>3</sup>/h for the D350 variant and 155 m<sup>3</sup>/h and 308 m<sup>3</sup>/h for the D450 variant.



| Detection |                 | Required components | Optional components |
|-----------|-----------------|---------------------|---------------------|
| Humidity  | CO <sub>2</sub> |                     |                     |
| Central   | Main rooms      | ■ + ■               | ■                   |
| Central   | All rooms       | ■ + ■ + ■           | ■                   |

→ Extraction of stale air  
 → Supply of fresh air

The illustration shows a right-hand variant of the DucoBox Energy Comfort (Plus).



LOCAL  
humidity  
measurement



# Duco Energy Comfort (Plus) System

MVHR | Zonal ventilation (2-zone) | Up to 550 m<sup>3</sup>/h (153 l/s) at 200 Pa



## BASIC KIT

|  |   |           |
|--|---|-----------|
|  | Basic kit Multizone D160<br>DucoBox Energy Comfort (Plus) / Sky White | 0000-4900 |
|--|---|-----------|


The bullet next to the item numbers below indicates which and how many components the basic kit contains.

## COMPONENTS

| Component on diagram |   |
|----------------------|---|
|                      | DucoBox Energy Comfort D250<br><b>available Q1/2026</b>                               |
| 1                    | DucoBox Energy Comfort D325 (UK)  |
| 1                    | DucoBox Energy Comfort D400 (UK)  |
| 1                    | DucoBox Energy Comfort Plus D250<br><b>available Q1/2026</b>                          |
| 1                    | DucoBox Energy Comfort Plus D350 (UK)   |
| 1                    | DucoBox Energy Comfort Plus D450 (UK)   |
| 1                    | DucoBox Energy Comfort Plus D550 (UK)   |
| 2                    | Multi-zone valve DucoBox Energy (Sensorless) Ø125                                     |
| 2                    | Multi-zone valve DucoBox Energy (Sensorless) Ø160                                     |
| 2                    | Duco Branch piece (Ø180 → 2x Ø160)<br>for Multi-zone valves                           |
| 3                    |   |
| 4                    | User controller RF / Wired White  |
| 4                    | User controller RF / Battery White  |
| 5                    | CO <sub>2</sub> Room sensor with control RF/Wired White                               |
| 5                    | CO <sub>2</sub> Room sensor without control RF / Wired White                          |
| 6                    | Humidity Room sensor with control RF / Wired White                                    |
| 6                    | Surface-mounted box DUZO controllers / sensors  |
| 7                    |   |
| 8                    |   |
| 9                    |   |
| 10                   | Switch sensor RF/230 VAC  |
|                      |   |
|                      | Duco Connectivity Board 2.0   |
|                      |   |
|                      | Pre-Heater DucoBox Energy Comfort (Plus) / Sky (UK) 1150W<br><b>available Q2/2026</b> |
|                      | Pre-Heater DucoBox Energy Comfort (Plus) (UK) 1425W                                   |
|                      |   |
|                      | Duco Power supply 230VAC-24VDC/20W + casing   |

→ See chapter 'Control components' from page 82 for black control components and more information on all user controllers & room sensors.

\* Passive House Institute certificate only for DucoBox Energy Comfort Plus D350/D450 units with pre-heater and a maximum flow rate between: 160 m<sup>3</sup>/h and 238 m<sup>3</sup>/h for the D350 variant and 155 m<sup>3</sup>/h and 308 m<sup>3</sup>/h for the D450 variant.



| Detection |                 | Required components   | Optional components                 |
|-----------|-----------------|---|-------------------------------------|
| Humidity  | CO <sub>2</sub> | <div style="border: 2px solid green; padding: 2px; display: inline-block;"> <span style="color: blue;">■</span> + <span style="color: teal;">■</span> </div>                                      | <span style="color: grey;">■</span> |
| Local     | Main rooms      | <div style="border: 2px solid green; padding: 2px; display: inline-block;"> <span style="color: blue;">■</span> + <span style="color: teal;">■</span> </div>                                      | <span style="color: grey;">■</span> |
| Local     | All rooms       | <div style="border: 2px solid green; padding: 2px; display: inline-block;"> <span style="color: blue;">■</span> + <span style="color: teal;">■</span> + <span style="color: red;">■</span> </div> | <span style="color: grey;">■</span> |

→ Extraction of stale air  
 → Supply of fresh air


The illustration shows a right-hand variant of the DucoBox Energy Comfort (Plus) system.



NEW

# DucoBox Energy Sky

The ideal ventilation solution for **COMPACT SPACES!**



## Easy to install

Via head-up display or  
via the Duco Installation App



## Save time = save money

AUTO calibration, COPY function,  
100% exchangeable via display



## Priority to energy savings

Smart demand control



Please refer to page 107 for essential installation tips!

## DucoBox Energy Sky

MVHR

Up to **275 m<sup>3</sup>/h** (76 l/s) at 200 Pa

Discover the DucoBox Energy Sky - **the ventilation solution for compact spaces** with a ventilation flow rate of 275 m<sup>3</sup>/h. With a height of just 30 cm and a light weight of 19 kg, the placement options are flexible. The system can be attached to the ceiling, as well as to the wall. It is also possible to neatly conceal this DucoBox in a false ceiling. Installation is easily done by one person.

The DucoBox Energy Sky automatically adjusts the ventilation to the actual need using the optional integrated 2-zone control. You thus automatically control the ventilation system based on CO<sub>2</sub> and humidity, allowing you to ventilate even more efficiently.

The DucoBox Energy Sky is part of The Energy Family and offers balanced ventilation with heat recovery, without compromise on performance.

### FEATURES

|  |   |  |
|--|---|--|
| <b>Connection type</b><br>1 x extraction to outside (EHA)<br>1 x supply from outside (ODA)<br>1 x extraction from inside (ETA)<br>1 x supply to inside (SUP) | <b>Energy label:</b> A+<br><b>Communication:</b><br>RF and Wired. Expandable with Connectivity Board 2.0 (see 'Options & accessories') for communication with the Duco Installation App and the DUCO HOME app, REST API and Modbus TCP. | <b>Width x Height x Depth:</b><br>670 x 1180 x 295 mm<br><b>Weight:</b> 19 kg<br><b>Flow rate / pressure:</b><br>275 m <sup>3</sup> /h (76 l/s) / 200 Pa<br><b>Number of air ducts:</b> 4 x Ø 160<br><b>Max. power per motor:</b> 65 W |
|--|---|--|


### VENTILATION UNIT



Type of DucoBox

Energy Sky D275 (UK)

0000-4940





## CONTROL COMPONENTS DucoBox Energy Sky

### → HUMIDITY SENSOR

This sensor is placed **in the extract air duct (ETA)** of the DucoBox Energy Sky and centrally measures the **humidity** of the air extracted from the house. **A maximum of one Humidity Sensor (ETA) per unit.**

|                   |                                   |                                |
|-------------------|-----------------------------------|--------------------------------|
| Peak power: < 1 W | Communication: via supplied cable | Power supply: From the DucoBox |
|-------------------|-----------------------------------|--------------------------------|



Humidity Sensor DucoBox Energy Comfort (Plus) / Sky **0000-4723**

The Humidity Sensor is installed in a borehole ( $\varnothing$  10mm) in an extraction duct with diameter of your choice.

### → EXTERNAL 2-ZONE

The 2-zone control for the supply to the home is done quickly and discreetly by the compact multi-zone valves. A valve is provided for each branch to the various zones.



|                 |  |  |
|-----------------|--|--|
| Peak power: 7 W | Communication: Wired connection to DucoBox | Power supply: 24 VDC (to be provided externally) |
|-----------------|--|--|

Multi-zone valve DucoBox Energy (Sensorless)  $\varnothing$ 125 **0000-4761**

Multi-zone valve DucoBox Energy (Sensorless)  $\varnothing$ 160 **0000-4760**



The Duco Branch piece ( $\varnothing$ 180  $\rightarrow$  2x  $\varnothing$ 160) has been developed to allow multi-zone valves to be quickly fitted to DucoBox Energy Comfort (Plus) / Sky. Thanks to the well-thought-out design, the pressure build-up is evenly distributed over both zones. This improves the acoustics of the overall system! By using the connection pieces with joint, the Branch piece can be fitted to any type of DUCO ventilation system. The multi-zone valves D160 can also be mounted airtight without additional material. Save time = save money!

Duco Branch piece ( $\varnothing$ 180  $\rightarrow$  2x  $\varnothing$ 160) for Multi-zone valves **0000-4995**

### → EXTERNAL CONTROL COMPONENTS

The DucoBox Energy Sky can be linked with the following external control components.

|                                      |             |
|--------------------------------------|-------------|
| User controllers & room sensors      | see page 82 |
| Switch sensor (for switch detection) | see page 84 |

### → BASIC KITS

Basic kit Multizone D160  
DucoBox Energy Comfort (Plus) / Sky White

2 x Multi-zone valve DucoBox Energy (Sensorless)  $\varnothing$ 160  
1 x CO<sub>2</sub> Room sensor with control **RF/Wired White**  
1 x CO<sub>2</sub> Room sensor without control **RF/Wired White**  
1 x Duco Power supply 230VAC-24VDC/20W + casing

**0000-4900**



Siphon flat (Energy) **0000-4376**

This flat diaphragm siphon with a height of 64 mm saves space and has less of a risk of air leaks. The siphon can be installed 'dry' and does not dry out on warm days.



Filterset 2 x Coarse 65% (Energy Sky D275) **0000-4950**

Filterset Coarse 65% / ePM1 55% (Energy Sky D275) **0000-4951**

The filter sets for the DucoBox Energy Sky include the following filters: For supply air (SUP): choice between Coarse 65% ( $\approx$  G4) or ePM1 55% filter ( $\approx$  F7). The ePM1 55% filter allows less fine particles to pass through and thus has a beneficial effect on air quality (e.g. in case of possible allergic reactions). For extract air (ETA): Coarse 65% filter ( $\approx$  G4)



Coaxial cable set 8 m **0000-4418**

The set comprises an 8 m long coaxial cable with pre-fitted connectors at both ends. This set can be used to relocate the DucoBox Silent Connect, DucoBox Focus or DucoBox Energy Comfort (Plus) / Sky / Premium antenna, if necessary, to a spot where the RF range is optimal.



## Duco Connectivity Board 2.0

0000-4945

The optional Duco Connectivity Board 2.0 offers the possibility of application within the DucoBox Silent Connect, DucoBox Focus and DucoBox Energy Comfort (Plus) / Sky / Premium, enabling communication with the Duco Installation App and DUCO HOME app, while also allowing integration into home automation and building management systems via REST API or Modbus TCP.



## Connection piece with joint D160/D125 (M/M)

0000-7087

available Q2/2026

## Connection piece with joint D160/D160 (M/M)

0000-4724

## Connection piece with joint D180/D160 (M/M)

0000-4725

## Connection piece 45° with joint D160/D160 (M/M)

0000-4949

The connection pieces with joint are used to make a quick and good connection between ducts (extraction and/or supply) or between a duct and a DucoBox. Thanks to the pre-fitted rubber seal, an airtightness class of up to D can be guaranteed at the connection!



## Insulated connection piece with joint D160/D125 (M/M)

0000-7136

available Q2/2026

## Insulated connection piece with joint D160/D160 (M/M)

0000-7039

## Insulated connection piece with joint D180/D160 (M/M)

0000-7040

## Insulated connection piece 45° with joint D160/D160 (M/M)

0000-7043

The connection pieces with joint are used to make a quick and good connection between ducts (extraction and/or supply) or between a duct and a DucoBox. Thanks to the pre-fitted rubber seal, an airtightness class of up to D can be guaranteed at the connection!



## Pre-Heater DucoBox Energy Comfort (Plus) / Sky (UK) 1150 W


0000-7003

available Q2/2026

The Pre-heater is a frost protection based on an electrical resistance of up to 1150W that can optionally be applied in the ODA connection of DucoBox Energy Sky. The resistance is modulatively controlled based on various temperature readings in the ventilation unit.

The heater is attached between the unit and the air duct via connectors. The connectors depend on the type of unit and the flow rate. Refer to the table below for the right combination.

| Type of unit | Flow rate                            | 1 Connector            | 2 Heater                          | 3 Connector            |
|--------------|--------------------------------------|------------------------|-----------------------------------|------------------------|
| Sky D275     | Up to 250 m <sup>3</sup> /h (69 l/s) | D160/D160<br>0000-7039 | Pre-Heater<br>1150 W<br>0000-7003 | D160/D160<br>0000-7039 |
|              | Up to 275 m <sup>3</sup> /h (76 l/s) | D180/D160<br>0000-7040 |                                   | D160/D160<br>0000-7039 |



## Duco Power supply 230VAC-24VDC/20W + casing

0000-4763

The Duco Power Supply 230VAC-24VDC/20W is the best solution to power Duco Wired components from a central 230V connection. The component comes with a surface-mounted junction box as standard. The sum of the peak power of all connected DUCO components can be 20W at most when using one Power Supply.

Flow regulator 15-50 m<sup>3</sup>/h Ø80

0000-4722

Flow regulator 15-50 m<sup>3</sup>/h Ø125

0000-4836

Flow regulator 50-100 m<sup>3</sup>/h Ø125

0000-4837

The adjustable flow regulator is an element that is placed in a duct to obtain a constant flow in a pressure range between 50 and 250 Pascal. It is used for both supply and extraction.




NO humidity measurement

1-ZONE  
SYSTEM

## COMPONENTS

| Component on diagram |  |
|----------------------|--|
| 1                    | DucoBox Energy Sky D275 (UK) <b>0000-4940</b>  |
| 2                    | User controller RF / Wired White <b>0000-4602</b><br>User controller RF / Battery White <b>0000-4600</b>                                       |
| 6                    | CO <sub>2</sub> Room sensor with control RF/Wired White <b>0000-4604</b>   |
| 3 4 5                | CO <sub>2</sub> Room sensor without control RF/Wired White <b>0000-4637</b><br>Surface-mounted box DUCO controllers / sensors <b>0000-5009</b> |
| 7                    | Switch sensor RF/230 VAC <b>0000-4174</b>  |
|                      | → See chapter 'Control components' from page 82 for black control components and more information on all user controllers & room sensors.      |
| 8                    | Duco Connectivity Board 2.0 <b>0000-4945</b>   |
|                      | → See chapter 'Vents' from page 92 for more information on all types of vents.   |
|                      | Pre-Heater DucoBox Energy Comfort (Plus) / Sky (UK) 1150W <b>0000-7003</b><br>available Q2/2026  |



| Detection |                 | Required components | Optional components |
|-----------|-----------------|---------------------|---------------------|
| Humidity  | CO <sub>2</sub> |                     |                     |
| ✗         | ✗               |                     |                     |
| ✗         | Main rooms      | ■                   | ■                   |
| ✗         | All rooms       | ■ + ■               | ■                   |

→ Extraction of stale air  
 → Supply of fresh air

CENTRAL  
humidity  
measurement1-ZONE  
SYSTEM

# Duco Energy Sky System


MVHR | Central ventilation (1-zone) | Up to 275 m<sup>3</sup>/h (76 l/s) at 200 Pa

## COMPONENTS

| Component on diagram |  |
|----------------------|--|
| 1                    | DucoBox Energy Sky D275 (UK) <b>0000-4940</b>  |
| 7                    | Humidity Sensor DucoBox Energy Comfort (Plus) / Sky <b>0000-4723</b>   |
| 2                    | User controller RF / Wired White <b>0000-4602</b><br>User controller RF / Battery White <b>0000-4600</b>   |
| 6                    | CO <sub>2</sub> Room sensor with control RF/Wired White <b>0000-4604</b>   |
| 3 4 5                | CO <sub>2</sub> Room sensor without control RF / Wired White <b>0000-4637</b><br>Surface-mounted box DUCO controllers / sensors <b>0000-5009</b> |
| 8                    | Switch sensor RF/230 VAC <b>0000-4174</b>  |
|                      | Duco Connectivity Board 2.0 <b>0000-4945</b>   |
|                      | Pre-Heater DucoBox Energy Comfort (Plus) / Sky (UK) <b>1150W 0000-7003</b><br>available Q2/2026  |


→ See chapter 'Control components' from page 82 for black control components and more information on all user controllers &amp; room sensors.

→ See chapter 'Vents' from page 92 for more information on all types of vents.



| Detection |                 | Required components | Optional components |
|-----------|-----------------|---------------------|---------------------|
| Humidity  | CO <sub>2</sub> | ■ + ■               | ■                   |
| Central   |                 | ■                   |                     |
| Central   | Main rooms      | ■ + ■ + ■           | ■                   |
| Central   | All rooms       | ■ + ■ + ■ + ■       | ■                   |

→ Extraction of stale air  
 → Supply of fresh air



LOCAL  
humidity  
measurement

1-ZONE  
SYSTEM

# Duco Energy Sky System


MVHR | Central ventilation (1-zone) | Up to 275 m<sup>3</sup>/h (76 l/s) at 200 Pa



## COMPONENTS

| Component on diagram |   |
|----------------------|---|
| 1                    | DucoBox Energy Sky D275 (UK) <b>0000-4940</b>   |
| 2                    | User controller RF / Wired White <b>0000-4602</b>   |
| 3                    | User controller RF / Battery White <b>0000-4600</b>   |
| 4                    | CO <sub>2</sub> Room sensor with control RF/Wired White <b>0000-4604</b>  |
| 5                    | CO <sub>2</sub> Room sensor without control RF / Wired White <b>0000-4637</b>   |
| 6                    | Humidity Room sensor with control RF / Wired White <b>0000-4606</b>   |
| 7                    | Surface-mounted box DUCO controllers / sensors <b>0000-5009</b>   |
|                      | → See chapter 'Control components' from page 82 for black control components and more information on all user controllers & room sensors. |
| 8                    | Switch sensor RF/230 VAC <b>0000-4174</b>   |
|                      | Duco Connectivity Board 2.0 <b>0000-4945</b>  |
|                      | Pre-Heater DucoBox Energy Comfort (Plus) / Sky (UK) 1150W <b>0000-7003</b><br>available Q2/2026   |

→ See chapter 'Vents' from page 92 for more information on all types of vents.



| Detection |                 | Required components | Optional components |
|-----------|-----------------|---------------------|---------------------|
| Humidity  | CO <sub>2</sub> |                     |                     |
| Local     | ×               |                     |                     |
| Local     | Main rooms      | ■ + ■               | ■                   |
| Local     | All rooms       | ■ + ■ + ■ + ■       | ■                   |

→ Extraction of stale air  
 → Supply of fresh air



NO humidity measurement



# Duco Energy Sky System

MVHR | Zonal ventilation (2-zone) | Up to 275 m<sup>3</sup>/h (76 l/s) at 200 Pa

## BASIC KIT

- Basic kit Multizone D160  
DucoBox Energy Comfort (Plus) / Sky White **0000-4900**

The bullet next to the item numbers below indicates which and how many components the basic kit contains.

## COMPONENTS



| Component                    | Item Number      | Component on diagram |
|------------------------------|------------------|----------------------|
| DucoBox Energy Sky D275 (UK) | <b>0000-4940</b> | 1                    |



|   |                  |     |
|---|------------------|-----|
| Multi-zone valve DucoBox Energy (Sensorless) Ø125           | <b>0000-4761</b> |     |
| Multi-zone valve DucoBox Energy (Sensorless) Ø160           | <b>0000-4760</b> | 3 4 |
| Duco Branch piece (Ø180 → 2x Ø160)<br>for Multi-zone valves | <b>0000-4995</b> |     |



|  |                  |       |
|--|------------------|-------|
| User controller RF / Wired White                             | <b>0000-4602</b> |       |
| User controller RF / Battery White                           | <b>0000-4600</b> | 2     |
| CO <sub>2</sub> Room sensor with control RF/Wired White      | <b>0000-4604</b> | 8     |
| CO <sub>2</sub> Room sensor without control RF / Wired White | <b>0000-4637</b> | 5 6 7 |
| Surface-mounted box DUCO controllers / sensors               | <b>0000-5009</b> |       |

→ See chapter 'Control components' from page 82 for black control components and more information on all user controllers & room sensors.



|                          |                  |   |
|--------------------------|------------------|---|
| Switch sensor RF/230 VAC | <b>0000-4174</b> | 9 |
|--------------------------|------------------|---|



|                             |                  |  |
|-----------------------------|------------------|--|
| Duco Connectivity Board 2.0 | <b>0000-4945</b> |  |
|-----------------------------|------------------|--|




|  |                  |  |
|--|------------------|--|
| Pre-Heater DucoBox Energy Comfort (Plus) / Sky (UK) 1150W<br>available Q2/2026 | <b>0000-7003</b> |  |
|--|------------------|--|



|  |                  |  |
|--|------------------|--|
| Duco Power supply 230VAC-24VDC/20W<br>+ casing | <b>0000-4763</b> |  |
|--|------------------|--|

→ See chapter 'Vents' from page 92 for more information on all types of vents.



| Detection |                 | Required components | Optional components |
|-----------|-----------------|---------------------|---------------------|
| Humidity  | CO <sub>2</sub> |                     |                     |
| ✗         | Main rooms      |                     |                     |
| ✗         | All rooms       | ■ + ■               | ■                   |

→ Extraction of stale air

→ Supply of fresh air

CENTRAL  
humidity  
measurement

# Duco Energy Sky System

MVHR | Zonal ventilation (2-zone) | Up to 275 m<sup>3</sup>/h (76 l/s) at 200 Pa

## BASIC KIT



Basic kit Multizone D160  
DucoBox Energy Comfort (Plus) / Sky White

0000-4900

The bullet next to the item numbers below indicates which and how many components the basic kit contains.

## COMPONENTS



DucoBox Energy Sky D275 (UK)

0000-4940

Component  
on diagram

1



Multi-zone valve DucoBox Energy (Sensorless) Ø125

0000-4761



Multi-zone valve DucoBox Energy (Sensorless) Ø160

2 0000-4760

4 5

Duco Branch piece (Ø180 → 2x Ø160)  
for Multi-zone valves

0000-4995



Humidity Sensor DucoBox Energy Comfort (Plus) / Sky

0000-4723

3



User controller RF / Wired White

0000-4602

2



User controller RF / Battery White

0000-4600

CO<sub>2</sub> Room sensor with control RF/Wired White

1 0000-4604

9

CO<sub>2</sub> Room sensor without control RF / Wired White

1 0000-4637

6 7 8

Surface-mounted box DUCO controllers / sensors

0000-5009

→ See chapter 'Control components' from page 82 for black control components and more information on all user controllers &amp; room sensors.



Switch sensor RF/230 VAC

0000-4174

10




Duco Connectivity Board 2.0

0000-4945

Pre-Heater DucoBox Energy Comfort (Plus) / Sky (UK) 1150W  
available Q2/2026Duco Power supply 230VAC-24VDC/20W  
+ casing

1 0000-4763

→ See chapter 'Vents' from page 92 for more information on all types of vents.



| Detection |                 | Required components | Optional components |
|-----------|-----------------|---------------------|---------------------|
| Humidity  | CO <sub>2</sub> |                     |                     |
| Central   | Main rooms      | ■ + ■               | ■                   |
| Central   | All rooms       | ■ + ■ + ■           | ■                   |

→ Extraction of stale air  
 → Supply of fresh air



LOCAL  
humidity  
measurement



2-ZONE  
SYSTEM

# Duco Energy Sky System

MVHR | Zonal ventilation (2-zone) | Up to 275 m<sup>3</sup>/h (76 l/s) at 200 Pa



## BASIC KIT



Basic kit Multizone D160  
DucoBox Energy Comfort (Plus) / Sky White

0000-4900

The bullet next to the item numbers below indicates which and how many components the basic kit contains.

## COMPONENTS



DucoBox Energy Sky D275 (UK) 0000-4940 1



Multi-zone valve DucoBox Energy (Sensorless) Ø125 0000-4761 2

Multi-zone valve DucoBox Energy (Sensorless) Ø160 0000-4760 3

Duco Branch piece (Ø180 → 2x Ø160)  
for Multi-zone valves 0000-4995



User controller RF / Wired White 0000-4602

User controller RF / Battery White 0000-4600

CO<sub>2</sub> Room sensor with control RF/Wired White 0000-4604 7

CO<sub>2</sub> Room sensor without control RF / Wired White 0000-4637 4

Humidity Room sensor with control RF / Wired White 0000-4606 5

Surface-mounted box DUCO controllers / sensors 0000-5009 6

→ See chapter 'Control components' from page 82 for black control components and more information on all user controllers & room sensors.



Switch sensor RF/230 VAC 0000-4174 10



Duco Connectivity Board 2.0 0000-4945



Pre-Heater DucoBox Energy Comfort (Plus) / Sky (UK) 1150W 0000-7003  
available Q2/2026



Duco Power supply 230VAC-24VDC/20W + casing 0000-4763 1

→ See chapter 'Vents' from page 92 for more information on all types of vents.

Component  
on diagram

1


2 3

7

4 5 6

8 9

10



| Detection |                 | Required components | Optional components |
|-----------|-----------------|---------------------|---------------------|
| Humidity  | CO <sub>2</sub> |                     |                     |
| Local     | Main rooms      | ■ + ■               | ■                   |
| Local     | All rooms       | ■ + ■ + ■           | ■                   |

→ Extraction of stale air

→ Supply of fresh air



# DucoBox Energy Premium

The **QUIETEST** MVHR system!



## Smart 2-zone control

Saving up to 40 % through smart zone control




## Quietest MVHR on the market

Enjoy a good night's sleep!



## Automatic calibration

Calibration at constant pressure saves up to 50 % on the configuration time



Please refer to  
page 107 for essential  
installation tips!

# DucoBox Energy Premium

MVHR

Up to **400 m³/h** (111 l/s) at 150 Pa

An **energy efficient operation** becomes more and more important as "passive" and "energy neutral"-houses become more and more widespread. The DucoBox Energy Premium fits perfectly within this evolution as a very high performance "balanced" ventilation unit, which raises MVHR (Mechanical Ventilation with Heat Recovery) to the next level.

The favourable positioning of the fan as well as high-grade absorbent material and a steel casing guarantee a **whisper-quiet operation**, especially in the living areas where this matters most (bedroom and living room)!

The DucoBox Energy Premium comes with an **A+ energy label** and is available in a 1-zone and a 2-zone version. The day and night-zone are being controlled separately by a valve which is integrated in the unit itself. This results in an **extremely efficient operation**: only ventilate when it is necessary and where it is necessary (e.g. minimal ventilation at night-time in the day-zone).

The **automatic calibration**, which is based on the principle of constant pressure, easily saves 50 % of the set-up time. At the same time, it gives 100 % peace of mind for a **qualitative installation** with the correct airflows.

## FEATURES

|   |  |   |
|---|--|---|
| <b>Width x Height x Depth:</b><br>740 x 957 x 585 mm<br><b>Weight:</b> 47 kg<br><b>Power supply:</b> 230 VAC<br><b>Peak power at 150 Pa:</b><br>2 x 60,5 W (325 m³/h / 460 m³/h)<br>2 x 91,5 W (400 m³/h / 570 m³/h)<br><b>Energy label:</b> A+<br><b>Efficiency in accordance with EU 1253/2014:</b><br>Types 325: 89 %<br>Types 400: 88 % | <b>Extraction capacity at 150 Pa:</b><br>Types 325: 325 m³/h (90 l/s)<br>Types 400: 400 m³/h (111 l/s)<br><b>Supply capacity at 150 Pa:</b><br>Types 325: 325 m³/h (90 l/s)<br>Types 400: 400 m³/h (111 l/s)<br><b>Communication:</b><br>RF and Wired. Expandable with Connectivity Board 2.0 (see 'Options & accessories') for communication with the Duco Installation App and the DUCO HOME app, REST API and Modbus TCP. | <b>Number of air ducts:</b><br>5 ducts:<br>1 x extraction to outside (EHA)<br>1 x supply from outside (ODA)<br>1 x extraction from inside (ETA)<br>2 x supply to inside (SUP)<br>Internal diameter Ø 160 mm<br>External diameter Ø 190 mm |
|---|--|---|



## VENTILATION UNIT



The DucoBox Energy Premium is available in a **left-hand variant** (= bevelled side left) and **right-hand variant** (= bevelled side right). On the bevelled side, an exhaust duct and supply duct are connected to the house (ETA and SUP).

The DucoBox Energy Premium is provided with frost protection through an imbalance method, which may be supplemented with an optional heater.

### → 1-ZONE VARIANT

| Type of DucoBox Energy      | Passive House Certified Component | Max. air flow at 150 Pa         | Heater | Plug | LEFT             | RIGHT            |
|-----------------------------|-----------------------------------|---------------------------------|--------|------|------------------|------------------|
| Premium <b>325-1ZS</b> (UK) | ×                                 | 325 m <sup>3</sup> /h (90 l/s)  | ×      | G    | <b>0000-4456</b> | <b>0000-4460</b> |
| Premium <b>325-1ZH</b> (UK) |                                   | 325 m <sup>3</sup> /h (90 l/s)  | yes    | G    | <b>0000-4457</b> | <b>0000-4461</b> |
| Premium <b>400-1ZS</b> (UK) | ×                                 | 400 m <sup>3</sup> /h (111 l/s) | ×      | G    | <b>0000-4464</b> | <b>0000-4468</b> |
| Premium <b>400-1ZH</b> (UK) | ×                                 | 400 m <sup>3</sup> /h (111 l/s) | yes    | G    | <b>0000-4465</b> | <b>0000-4469</b> |

### → 2-ZONE VARIANT

| Type of DucoBox Energy      | Passive House Certified Component | Max. air flow at 150 Pa         | Heater | Plug | LEFT             | RIGHT            |
|-----------------------------|-----------------------------------|---------------------------------|--------|------|------------------|------------------|
| Premium <b>325-2ZS</b> (UK) | ×                                 | 325 m <sup>3</sup> /h (90 l/s)  | ×      | G    | <b>0000-4458</b> | <b>0000-4462</b> |
| Premium <b>325-2ZH</b> (UK) |                                   | 325 m <sup>3</sup> /h (90 l/s)  | yes    | G    | <b>0000-4459</b> | <b>0000-4463</b> |
| Premium <b>400-2ZS</b> (UK) | ×                                 | 400 m <sup>3</sup> /h (111 l/s) | ×      | G    | <b>0000-4466</b> | <b>0000-4470</b> |
| Premium <b>400-2ZH</b> (UK) | ×                                 | 400 m <sup>3</sup> /h (111 l/s) | yes    | G    | <b>0000-4467</b> | <b>0000-4471</b> |

1Z = 1 zone | 2Z = 2 zones

S = without heater | H = with heater

## CONTROL COMPONENTS DucoBox Energy Premium



### → BOX SENSOR

This sensor is fitted in the DucoBox Energy Premium and it measures the **humidity content** of the air extracted from the dwelling. A maximum of one Humidity Box sensor per unit.

|                   |                       |                                |
|-------------------|-----------------------|--------------------------------|
| Peak power: < 1 W | Stand-by power: < 1 W | Power supply: From the DucoBox |
|-------------------|-----------------------|--------------------------------|

Humidity Box sensor (Energy Premium)

**0000-4374**

### → EXTERNAL CONTROL COMPONENTS

The DucoBox Energy Premium can be linked with the following external control components.

|                                      |             |
|--------------------------------------|-------------|
| User controllers & room sensors      | see page 82 |
| Switch sensor (for switch detection) | see page 84 |

## OPTIONS & ACCESSORIES DucoBox Energy Premium



|  |                  |
|--|------------------|
| Mounting chair standing (Energy Premium) | <b>0000-4740</b> |
|--|------------------|

In situations where wall mounting of the DucoBox Energy Premium is not possible, this support frame makes floor mounting possible. Use of a flat siphon is required.

Width x Height x Depth (incl. DucoBox Energy Premium): 740 x 1110 x 570 mm



## Mounting chair hanging (Energy Premium)

**0000-4422**

In situations where it is not possible to mount the DucoBox to a wall, this support frame makes floor-mounting possible. Use of a standard siphon is possible.

Width x Height x Depth (incl. DucoBox Energy Premium): 740 x 1290 x 640 mm



## Filter set 2 x Coarse 65% (Energy Premium)

**0000-4417**

## Filter set Coarse 65% / ePM1 55% (Energy Premium)

**0000-4416**

The filter sets for the DucoBox Energy Premium include the following filters. For supply air (SUP): choice between Coarse 65% (= G4) or ePM1 55% filter (= F7) (Energy Premium only). The ePM1 55% filter allows less fine particles to pass through and thus has a beneficial effect on air quality (e.g. in case of possible allergic reactions). For extract air (ETA): Coarse 65% filter (= G4)



## Siphon flat (Energy)

**0000-4376**

This flat diaphragm siphon with a height of 64 mm saves space and has less of a risk of air leaks. The siphon can be installed 'dry' and does not dry out on warm days.



## Duco Connectivity Board 2.0

**0000-4945**

The optional Duco Connectivity Board 2.0 offers the possibility of application within the DucoBox Silent Connect, DucoBox Focus and DucoBox Energy Comfort (Plus) / Sky / Premium, enabling communication with the Duco Installation App and DUCO HOME app, while also allowing integration into home automation and building management systems via REST API or Modbus TCP.



## Coaxial cable set 8 m

**0000-4418**

The set comprises an 8 m long coaxial cable with pre-fitted connectors at both ends. This set can be used to relocate the DucoBox Silent Connect, DucoBox Focus or DucoBox Energy Comfort / Premium antenna, if necessary, to a spot where the RF range is optimal.

Connection piece with joint D160/D125 (M/M)  
available Q2/2026**0000-7087**

## Connection piece with joint D160/D160 (M/M)

**0000-4724**

## Connection piece with joint D180/D160 (M/M)

**0000-4725**

## Connection piece with joint D180/D180 (M/M)

**0000-4726**

## Connection piece with joint D200/D180 (M/M)

**0000-4727**

## Connection piece 45° with joint D160/D160 (M/M)

**0000-4949**

The connection pieces with joint are used to make a quick and good connection between ducts (extraction and/or supply) or between a duct and a DucoBox. Thanks to the pre-fitted rubber seal, an airtightness class of up to D can be guaranteed at the connection!

Insulated connection piece with joint D160/D125 (M/M)  
available Q2/2026**0000-7136**

## Insulated connection piece with joint D160/D160 (M/M)

**0000-7039**

## Insulated connection piece with joint D180/D160 (M/M)

**0000-7040**

## Insulated connection piece with joint D180/D180 (M/M)

**0000-7041**

## Insulated connection piece with joint D200/D180 (M/M)

**0000-7042**

## Insulated connection piece 45° with joint D160/D160 (M/M)

**0000-7043**

The connection pieces with joint are used to make a quick and good connection between ducts (extraction and/or supply) or between a duct and a DucoBox. Thanks to the pre-fitted rubber seal, an airtightness class of up to D can be guaranteed at the connection!



## Duco Power supply 230VAC-24VDC/20W + casing

**0000-4763**

The Duco Power Supply 230VAC-24VDC/20W is the best solution to power Duco Wired components from a central 230V connection. The component comes with a surface-mounted junction box as standard. The sum of the peak power of all connected DUCO components can be 20W at most when using one Power Supply.



## Flow regulator 15-50 m³/h Ø80

**0000-4722**

## Flow regulator 15-50 m³/h Ø125

**0000-4836**

## Flow regulator 50-100 m³/h Ø125

**0000-4837**

The adjustable flow regulator is an element that is placed in a duct to obtain a constant flow in a pressure range between 50 and 250 Pascal. It is used for both supply and extraction.



# Duco Energy Premium System

MVHR | Central ventilation (1-zone) | Up to 400 m<sup>3</sup>/h (111 l/s) at 150 Pa



NO humidity measurement



1-ZONE  
SYSTEM



## COMPONENTS

|  | Left             | Right            | Component on diagram |
|--|------------------|------------------|----------------------|
| DucoBox Energy Premium <b>325-1ZS</b> (UK) | <b>0000-4456</b> | <b>0000-4460</b> |                      |
| DucoBox Energy Premium <b>325-1ZH</b> (UK) | <b>0000-4457</b> | <b>0000-4461</b> |                      |
| DucoBox Energy Premium <b>400-1ZS</b> (UK) | <b>0000-4464</b> | <b>0000-4468</b> |                      |
| DucoBox Energy Premium <b>400-1ZH</b> (UK) | <b>0000-4465</b> | <b>0000-4469</b> |                      |

S = standard | H = with heater

User controller **RF / Wired White** **0000-4602**

User controller **RF / Battery White** **0000-4600**

CO<sub>2</sub> Room sensor with control **RF/Wired White** **0000-4604**

CO<sub>2</sub> Room sensor without control **RF / Wired White** **0000-4637**

Surface-mounted box DUCO controllers / sensors **0000-5009**

→ See chapter 'Control components' from page 82 for black control components and more information on all user controllers & room sensors.

Switch sensor **RF/230 VAC** **0000-4174**

Duco Connectivity Board 2.0 **0000-4945**

Component on diagram

1

2


6

3 4 5

7

→ See chapter 'Vents' from page 92 for more information on all types of vents.

\* Passive House Institute certificate only for DucoBox Energy Premium units with heater and a maximum flow rate between 119 m<sup>3</sup>/h and 239 m<sup>3</sup>/h.



| Detection |                 | Required components | Optional components |
|-----------|-----------------|---------------------|---------------------|
| Humidity  | CO <sub>2</sub> |                     |                     |
| ✗         | ✗               |                     |                     |
| ✗         | Main rooms      | ■                   | ■                   |
| ✗         | All rooms       | ■ + ■               | ■                   |

→ Extraction of stale air  
 → Supply of fresh air

The illustration shows a right variant of the DucoBox Energy Premium.



# Duco Energy Premium System

MVHR | Central ventilation (1-zone) | Up to 400 m<sup>3</sup>/h (111 l/s) at 150 Pa



**CENTRAL**  
humidity  
measurement




## COMPONENTS

|   |  | Left             | Right            | Component on diagram |
|---|--|------------------|------------------|----------------------|
| DucoBox Energy Premium <b>325-1ZS</b> (UK)  |  | <b>0000-4456</b> | <b>0000-4460</b> |                      |
| DucoBox Energy Premium <b>325-1ZH</b> (UK)  |  | <b>0000-4457</b> | <b>0000-4461</b> |                      |
| DucoBox Energy Premium <b>400-1ZS</b> (UK)  |  | <b>0000-4464</b> | <b>0000-4468</b> |                      |
| DucoBox Energy Premium <b>400-1ZH</b> (UK)  |  | <b>0000-4465</b> | <b>0000-4469</b> |                      |
| S = standard   H = with heater  |  |                  |                  |                      |
| Humidity Box sensor (Energy Premium)  |  |                  | <b>0000-4374</b> | <b>7</b>             |
| User controller RF / Wired White  |  |                  | <b>0000-4602</b> |                      |
| User controller RF / Battery White  |  |                  | <b>0000-4600</b> | <b>2</b>             |
| CO <sub>2</sub> Room sensor with control RF/Wired White   |  |                  | <b>0000-4604</b> | <b>6</b>             |
| CO <sub>2</sub> Room sensor without control RF/Wired White  |  |                  | <b>0000-4637</b> | <b>3 4 5</b>         |
| Humidity Room sensor with control RF / Wired White  |  |                  | <b>0000-4606</b> |                      |
| Surface-mounted box DUCO controllers / sensors  |  |                  | <b>0000-5009</b> |                      |
| → See chapter 'Control components' from page 82 for black control components and more information on all user controllers & room sensors. |  |                  |                  |                      |
| Switch sensor RF/230 VAC  |  |                  | <b>0000-4174</b> | <b>8</b>             |
| Duco Connectivity Board 2.0   |  |                  | <b>0000-4945</b> |                      |

→ See chapter 'Vents' from page 92 for more information on all types of vents.

\* Passive House Institute certificate only for DucoBox Energy Premium units with heater and a maximum flow rate between 119 m<sup>3</sup>/h and 239 m<sup>3</sup>/h.



| Detection |                 | Required components | Optional components |
|-----------|-----------------|---------------------|---------------------|
| Humidity  | CO <sub>2</sub> |                     |                     |
| Central   | ×               | ■ + ■               | ■                   |
| Central   | Main rooms      | ■ + ■ + ■           | ■                   |
| Central   | All rooms       | ■ + ■ + ■ + ■       | ■                   |

→ Extraction of stale air  
 → Supply of fresh air

The illustration shows a right variant of the DucoBox Energy Premium.



LOCAL  
humidity  
measurement



## COMPONENTS

|  | Left             | Right            | Component on diagram |
|--|------------------|------------------|----------------------|
| DucoBox Energy Premium <b>325-1ZS</b> (UK) | <b>0000-4456</b> | <b>0000-4460</b> |                      |
| DucoBox Energy Premium <b>325-1ZH</b> (UK) | <b>0000-4457</b> | <b>0000-4461</b> |                      |
| DucoBox Energy Premium <b>400-1ZS</b> (UK) | <b>0000-4464</b> | <b>0000-4468</b> |                      |
| DucoBox Energy Premium <b>400-1ZH</b> (UK) | <b>0000-4465</b> | <b>0000-4469</b> |                      |

S = standard | H = with heater

|                                      |                  |  |
|--------------------------------------|------------------|--|
| Humidity Box sensor (Energy Premium) | <b>0000-4374</b> |  |
|--------------------------------------|------------------|--|

|                                    |                  |  |
|------------------------------------|------------------|--|
| User controller RF / Wired White   | <b>0000-4602</b> |  |
| User controller RF / Battery White | <b>0000-4600</b> |  |

|  |                  |  |
|--|------------------|--|
| CO <sub>2</sub> Room sensor with control RF/Wired White    | <b>0000-4604</b> |  |
| CO <sub>2</sub> Room sensor without control RF/Wired White | <b>0000-4637</b> |  |

|  |                  |  |
|--|------------------|--|
| Humidity Room sensor with control RF / Wired White | <b>0000-4606</b> |  |
| Surface-mounted box DUZO controllers / sensors     | <b>0000-5009</b> |  |


→ See chapter 'Control components' from page 82 for black control components and more information on all user controllers & room sensors.

|                          |                  |  |
|--------------------------|------------------|--|
| Switch sensor RF/230 VAC | <b>0000-4174</b> |  |
|--------------------------|------------------|--|

|                             |                  |  |
|-----------------------------|------------------|--|
| Duco Connectivity Board 2.0 | <b>0000-4945</b> |  |
|-----------------------------|------------------|--|

→ See chapter 'Vents' from page 92 for more information on all types of vents.

\* Passive House Institute certificate only for DucoBox Energy Premium units with heater and a maximum flow rate between 119 m<sup>3</sup>/h and 239 m<sup>3</sup>/h.



| Detection |                 | Required components | Optional components |
|-----------|-----------------|---------------------|---------------------|
| Humidity  | CO <sub>2</sub> |                     |                     |
| Local     | ×               |                     |                     |
| Local     | Main rooms      | ■ + ■               | ■                   |
| Local     | All rooms       | ■ + ■ + ■ + ■       | ■                   |

→ Extraction of stale air  
 → Supply of fresh air

The illustration shows a right variant of the DucoBox Energy Premium.



NO humidity measurement



# Duco Energy Premium System


MVHR | Central ventilation (2-zone) | Up to 400 m<sup>3</sup>/h (111 l/s) at 150 Pa

## COMPONENTS

|   | Left             | Right            | Component on diagram |  |  |
|---|------------------|------------------|----------------------|--|--|
| DucoBox Energy Premium <b>325-2ZS</b> (UK)  | <b>0000-4458</b> | <b>0000-4462</b> |                      |  |  |
| DucoBox Energy Premium <b>325-2ZH</b> (UK)  | <b>0000-4459</b> | <b>0000-4463</b> |                      |  |  |
| DucoBox Energy Premium <b>400-2ZS</b> (UK)  | <b>0000-4466</b> | <b>0000-4470</b> |                      |  |  |
| DucoBox Energy Premium <b>400-2ZH</b> (UK)  | <b>0000-4467</b> | <b>0000-4471</b> |                      |  |  |
| S = standard   H = with heater  |                  |                  |                      |  |  |
| User controller <b>RF / Wired White</b>   | <b>0000-4602</b> |                  |                      |  |  |
| User controller <b>RF / Battery White</b>   | <b>0000-4600</b> |                  |                      |  |  |
| CO <sub>2</sub> Room sensor with control <b>RF/Wired White</b>  | <b>0000-4604</b> |                  | 5                    |  |  |
| CO <sub>2</sub> Room sensor without control <b>RF / Wired White</b>   | <b>0000-4637</b> |                  | 2   3   4            |  |  |
| Surface-mounted box DUCO controllers / sensors  | <b>0000-5009</b> |                  |                      |  |  |
| → See chapter 'Control components' from page 82 for black control components and more information on all user controllers & room sensors. |                  |                  |                      |  |  |
| Switch sensor <b>RF/230 VAC</b>   | <b>0000-4174</b> |                  | 6                    |  |  |
| Duco Connectivity Board 2.0   |                  |                  |                      |  |  |
| <b>0000-4945</b>  |                  |                  |                      |  |  |

→ See chapter 'Vents' from page 92 for more information on all types of vents.

\* Passive House Institute certificate only for DucoBox Energy Premium units with heater and a maximum flow rate between 119 m<sup>3</sup>/h and 239 m<sup>3</sup>/h.



| Detection |                 | Required components | Optional components |
|-----------|-----------------|---------------------|---------------------|
| Humidity  | CO <sub>2</sub> |                     |                     |
| ×         | ×               |                     |                     |
| ×         | Main rooms      | ■                   | ■                   |
| ×         | All rooms       | ■ + ■               | ■                   |

The illustration shows a right variant of the DucoBox Energy Premium.

→ Extraction of stale air  
→ Supply of fresh air

CENTRAL  
humidity  
measurementcool, temperate climate  
CERTIFIED  
COMPONENT  
Passive House Institute

\* Passive House Institute certificate only for DucoBox Energy Premium units with heater and a maximum flow rate between 119 m³/h and 239 m³/h.

# Duco Energy Premium System

MVHR | Central ventilation (2-zone) | Up to 400 m³/h (111 l/s) at 150 Pa




## COMPONENTS

|   | Left             | Right            | Component<br>on diagram |
|---|------------------|------------------|-------------------------|
| DucoBox Energy Premium <b>325-2ZS</b> (UK)  | <b>0000-4458</b> | <b>0000-4462</b> |                         |
| DucoBox Energy Premium <b>325-2ZH</b> (UK)  | <b>0000-4459</b> | <b>0000-4463</b> | 1                       |
| DucoBox Energy Premium <b>400-2ZS</b> (UK)  | <b>0000-4466</b> | <b>0000-4470</b> |                         |
| DucoBox Energy Premium <b>400-2ZH</b> (UK)  | <b>0000-4467</b> | <b>0000-4471</b> |                         |
| S = standard   H = with heater  |                  |                  |                         |
| Humidity Box sensor (Energy Premium)  | <b>0000-4374</b> |                  | 6                       |
| User controller RF / Wired White  | <b>0000-4602</b> |                  |                         |
| User controller RF / Battery White  | <b>0000-4600</b> |                  |                         |
| CO <sub>2</sub> Room sensor with control RF/Wired White   | <b>0000-4604</b> |                  | 5                       |
| CO <sub>2</sub> Room sensor without control RF / Wired White  | <b>0000-4637</b> |                  | 2 3 4                   |
| Surface-mounted box DUZO controllers / sensors  | <b>0000-5009</b> |                  |                         |
| → See chapter 'Control components' from page 82 for black control components and more information on all user controllers & room sensors. |                  |                  |                         |
| Switch sensor RF/230 VAC  | <b>0000-4174</b> |                  | 7                       |
| Duco Connectivity Board 2.0   | <b>0000-4945</b> |                  |                         |

→ See chapter 'Vents' from page 92 for more information on all types of vents.

\* Passive House Institute certificate only for DucoBox Energy Premium units with heater and a maximum flow rate between 119 m³/h and 239 m³/h.



| Detection |                 | Required components | Optional components |
|-----------|-----------------|---------------------|---------------------|
| Humidity  | CO <sub>2</sub> |                     |                     |
| Central   | ×               |                     |                     |
| Central   | Main rooms      | ■ + ■               | ■                   |
| Central   | All rooms       | ■ + ■ + ■ + ■       | ■                   |

The illustration shows a right variant of the DucoBox Energy Premium.



# Duco Energy Premium System

MVHR | Zonal ventilation (2-zone) | Up to 400 m<sup>3</sup>/h (111 l/s) at 150 Pa




## COMPONENTS

|   | Left             | Right            | Component on diagram |
|---|------------------|------------------|----------------------|
| DucoBox Energy Premium <b>325-2ZS</b> (UK)  | <b>0000-4458</b> | <b>0000-4462</b> |                      |
| DucoBox Energy Premium <b>325-2ZH</b> (UK)  | <b>0000-4459</b> | <b>0000-4463</b> |                      |
| DucoBox Energy Premium <b>400-2ZS</b> (UK)  | <b>0000-4466</b> | <b>0000-4470</b> |                      |
| DucoBox Energy Premium <b>400-2ZH</b> (UK)  | <b>0000-4467</b> | <b>0000-4471</b> |                      |
| S = standard   H = with heater  |                  |                  |                      |
| User controller <b>RF / Wired White</b>   | <b>0000-4602</b> |                  |                      |
| User controller <b>RF / Battery White</b>   | <b>0000-4600</b> |                  |                      |
| CO <sub>2</sub> Room sensor <b>with control RF/Wired White</b>  | <b>0000-4604</b> |                  | 5                    |
| CO <sub>2</sub> Room sensor <b>without control RF / Wired White</b>   | <b>0000-4637</b> |                  | 2 3 4                |
| Humidity Room sensor <b>with control RF / Wired White</b>   | <b>0000-4606</b> |                  | 6 7                  |
| Surface-mounted box <b>DUCO controllers / sensors</b>   | <b>0000-5009</b> |                  |                      |
| → See chapter 'Control components' from page 82 for black control components and more information on all user controllers & room sensors. |                  |                  |                      |
| Switch sensor <b>RF/230 VAC</b>   | <b>0000-4174</b> |                  | 8                    |
| Duco Connectivity Board 2.0   | <b>0000-4945</b> |                  |                      |

→ See chapter 'Vents' from page 92 for more information on all types of vents.

\* Passive House Institute certificate only for DucoBox Energy Premium units with heater and a maximum flow rate between 119 m<sup>3</sup>/h and 239 m<sup>3</sup>/h.



| Detection |                 | Required components | Optional components |
|-----------|-----------------|---------------------|---------------------|
| Humidity  | CO <sub>2</sub> |                     |                     |
| Local     | ×               |                     |                     |
| Local     | Main rooms      | ■ + ■               | ■                   |
| Local     | All rooms       | ■ + ■ + ■ + ■       | ■                   |

The illustration shows a right variant of the DucoBox Energy Premium.

→ Extraction of stale air  
 → Supply of fresh air



## CONTROL COMPONENTS

With DUKO each ventilation system can be custom assembled using modular control components.





## USER CONTROLLERS & ROOM SENSORS

User controllers and room sensors contain **one or both** of the following functions:

### User controller

Using the buttons, the user sets the operation of the ventilation system to the desired level:

- Automatic mode (recommended): CO<sub>2</sub> and/or humidity measurements determine the operation of the ventilation system via intelligent algorithms. This guarantees optimum air quality in the most efficient way.
- Manual settings: the ventilation system ventilates at POS setting 1, POS setting 2 or POS setting 3.

### Measuring air quality

Sensors continuously measure the CO<sub>2</sub> or humidity level (as well as temperature) in the rooms where they are installed. The measurements determine the operation of the ventilation system when it is in automatic mode.

All controls and room sensors also function as RF repeaters (except battery-operated controls).

| RF/Wired models  | Battery-powered model   |
|--|---|
| <b>Power supply:</b> RF: 230 VAC   Wired: 24 VDC<br><b>Width x Height x Depth:</b> 69 x 69 x 55 mm<br><b>Display:</b> 4 RGB LEDs<br><b>Peak power:</b> 1.8 W   <b>Stand-by power:</b> 1.2 W<br><b>Communication:</b> RF and wired<br><b>Colour:</b> black or white | <b>Battery:</b> CR2430 3V coin cell battery<br><b>Width x Height x Depth:</b> 69 x 69 x 17 mm<br><b>Display:</b> 1 bicolor LED<br><b>Communication:</b> RF<br><b>Colour:</b> black or white |



### User controllers + air quality measurement

These contain both a **user controller** and **room sensors** (CO<sub>2</sub> or humidity) for air quality measurement.

|  |                  |
|--|------------------|
| CO <sub>2</sub> Room sensor with control <b>RF/Wired White</b> | <b>0000-4604</b> |
| CO <sub>2</sub> Room sensor with control <b>RF/Wired Black</b> | <b>0000-7114</b> |
| Humidity Room sensor with control <b>RF / Wired White</b>      | <b>0000-4606</b> |
| Humidity Room sensor with control <b>RF / Wired Black</b>      | <b>0000-7115</b> |



### User controller only

These contain only a **user controller**. Ideal in rooms where measurement is not required, or where measurement is done by other means (in the duct).

|   |                  |
|---|------------------|
| User controller <b>RF / Battery White</b> | <b>0000-4600</b> |
| User controller <b>RF / Battery Black</b> | <b>0000-7111</b> |
| User controller <b>RF / Wired White</b>   | <b>0000-4602</b> |
| User controller <b>RF / Wired Black</b>   | <b>0000-7112</b> |



### Air quality measurement only

Room sensors that are only equipped with a **CO<sub>2</sub> sensor**. Ideal for bedrooms where no user controller is necessary.

|   |                  |
|---|------------------|
| CO <sub>2</sub> Room sensor without control <b>RF / Wired White</b> | <b>0000-4637</b> |
| CO <sub>2</sub> Room sensor without control <b>RF / Wired Black</b> | <b>0000-7113</b> |



### Surface-mounted box

By using the optional surface-mounted box, DUCO controllers and sensors can be easily applied in renovation projects.

|  |                  |
|--|------------------|
| Surface-mounted box DUCO controllers / sensors | <b>0000-5009</b> |
|--|------------------|

## WIRED COMPONENTS

Wired / 24 VDC components require a **transformer from 230 VAC to 24 VDC**. It is possible to work with a Duco Power supply as a central power supply to power the component from the wall socket. See "Options & accessories" for the ventilation unit.



## SWITCH SENSOR



The Switch Sensor can perform either or both of the following functions:

**Switch detection:** the ventilation system will perform a function when closing a (two-pole) dry contact. Suitable for toilet detection or overrule setting (only one function per switch sensor).

**Repeater:** the switch sensor is ideally suited as a repeater to strengthen the signal in the event of RF communication problems. In that case the switch sensor must be positioned in such a way that the distance to be bridged and/or interference by obstacles is reduced.

A switch sensor is easy to conceal thanks to its small size.

|  |   |  |
|--|---|--|
| <b>Width x Height x Depth:</b> 41 x 37 x 20 mm<br><b>Weight:</b> 21 g<br><b>Color:</b> white | <b>Peak power:</b> 0.5 W<br><b>Standby power:</b> 0.4 W | <b>Power supply:</b> 230 VAC<br><b>Communication:</b> RF |
|--|---|--|

**Note:** An external switch sensor is not required if a switch is connected to the onboard dry contact on the circuit board of the 'master' unit (DucoBox or IQ unit). Use a double-pole switch or relay and a 2 x 0.8 mm<sup>2</sup>cable for this. Refer to the [Onboard dry contact information sheet \(L8001001\)](#) for connection instructions.



Switch sensor RF/230 VAC


0000-4174



## → INTERNAL CONTROL COMPONENTS

Control components which are specific for a certain ventilation unit can be found on the corresponding ventilation unit page:


|                          |             |
|--------------------------|-------------|
| DucoBox Reno             | see page 16 |
| DucoBox Silent (Connect) | see page 22 |
| DucoBox Focus            | see page 28 |
| DucoBox Energy Comfort   | see page 33 |
| DucoBox Energy Sky       | see page 51 |
| DucoBox Energy Premium   | see page 67 |



## DUCOFLEX AIR DUCT SYSTEM

With DucoFlex, DUCO offers a **complete air duct system** for MEV and MVHR systems. It consists of the highest airtightness class D, the lowest air resistance and maximum acoustic comfort in combination with the quietest ventilation boxes! The result is an **energy-efficient and quiet** ventilation system.

Did you know that this complete air duct system for MEV and MVHR systems is very **installation-friendly**? This is thanks to the handy 'Click & Go' principle and minimum number of fittings. DUCO as a one-stop-shop with 100% service provision!



## DUCOFLEX IN 3 STEPS

Are you convinced by DucoFlex, the compact and installation-friendly air duct system? In this case you will not be left on your own! DUCO will give you peace of mind for your tailor-made project.

- 1** **Provide your DUCO dealer with the necessary documents:** the building plans to scale in PDF format, the chosen configuration and the intended location for the DucoBox. Then your dealer will get started!
- 2** What's next? **You will receive a tailored quotation** with which you can approach your customer immediately. The calculation includes the price for the DucoBox, the system components and an estimate for the DucoFlex air-duct system.
- 3** Are you happy with the quotation? In this case you will receive a proposal for a **layout plan** within 10 work days and the completed **bill of materials** for MVHR systems.\*

\* Only applicable for MVHR systems. Between the estimate (quotation phase) and the completed bill of materials, fluctuations are possible in relation to the number of metres of DucoFlex or manifold boxes, depending on the complexity of the practical development.



## STANDARD COMPONENTS



|  |           |
|--|-----------|
| DucoFlex Round semi-rigid ducting D63 (50 m) | 0000-4552 |
| DucoFlex Round semi-rigid ducting D75 (50 m) | 0000-4674 |
| DucoFlex Round semi-rigid ducting D90 (50 m) | 0000-4692 |

DucoFlex antistatic and antibacterial air ducting, being round and flexible, is easy to fit. When fitted correctly, its low internal resistance will contribute to an energy-efficient ventilation system. The recommended range of application for Ø63 is up to 25 m<sup>3</sup>/h (7 l/s) per duct, for Ø75 up to 36 m<sup>3</sup>/h (10 l/s) per duct and for Ø90 up to 50 m<sup>3</sup>/h (14 l/s) per duct.



|  |           |
|--|-----------|
| DucoFlex Rubber O-ring D63 (10 pieces) | 0000-4553 |
| DucoFlex Rubber O-ring D75 (10 pieces) | 0000-4675 |
| DucoFlex Rubber O-ring D90 (10 pieces) | 0000-4676 |

The DucoFlex O-ring (EPDM) provides a quick and perfectly airtight joint between air ducts and fittings.



|                       |           |
|-----------------------|-----------|
| DucoFlex Coupling D63 | 0000-4554 |
| DucoFlex Coupling D75 | 0000-4677 |
| DucoFlex Coupling D90 | 0000-4678 |

The coupling enables an airtight connection to be made between DucoFlex ducts. A built-in stop prevents the ducts from being inserted too far.



|                        |           |
|------------------------|-----------|
| DucoFlex Elbow 90° D75 | 0000-4679 |
| DucoFlex Elbow 90° D90 | 0000-4680 |

The elbow in the standard configuration enables a 90° bend to be made in flexible ducting.



|   |           |
|---|-----------|
| DucoFlex 90° Bend splitter vent connector long, oval D125 | 0000-4681 |
|---|-----------|

The DucoFlex 90° Bend splitter vent connector long can be utilised multifunctionally. This makes it possible to connect a DucoFlex connector 3x63, 2x75, 3x75 or 2x90 to it. Suitable for a transit size up to 300 mm.



|  |           |
|--|-----------|
| DucoFlex 90° Bend splitter vent connector short, oval D125 | 0000-4682 |
|--|-----------|

The DucoFlex 90° Bend splitter vent connector short can be used multifunctionally. This makes it possible to connect a DucoFlex connector 3x63, 2x75, 3x75 or 2x90 to it. Suitable for a transit size up to 60 mm (e.g. wide slab floor).



|   |           |
|---|-----------|
| DucoFlex Manifold box (floor and ceiling) 4 x oval air ducts (F) D160 | 0000-4687 |
|---|-----------|

The ceiling and floor manifold box can be utilised multifunctionally. It is a box with 4 oval connexions and a D160 riser duct. In combination with connectors D63, D75 or D90, it becomes a floor/ceiling plenum.



|  |           |
|--|-----------|
| DucoFlex Manifold box (floor and ceiling) 3x oval air ducts (F) 1x oval air duct (M) | 0000-4701 |
|--|-----------|

The ceiling and floor manifold box can be utilised multifunctionally. It is a manifold box with 3 oval connections (F) and 1 oval connection (M). This offers the possibility to connect it to the ceiling and floor manifold box 4x oval (F) and so expand to 6x oval connections (F).



|   |           |
|---|-----------|
| DucoFlex Manifold box (floor) 12x63 D180 (expiring) | 0000-4563 |
|---|-----------|

The D180 floor manifold box is the adapter between a maximum of 12 DucoFlex D63 ducts and a direct connection to a D180 riser duct. The smart 'Click & Go' system provides a quick and perfectly airtight joint between DucoFlex ducts.



|  |           |
|--|-----------|
| DucoFlex Manifold box (floor) 12x63 2x oval air ducts (expiring) | 0000-4565 |
|--|-----------|

The 2x oval floor manifold box is the adapter between up to a maximum of 12 D63 ducts and 2x DucoFlex oval. This enables the manifold box to be positioned more accessibly. The smart 'Click & Go' system provides a quick and perfectly airtight joint between DucoFlex ducts.



DucoFlex Manifold box (ceiling) 12x63 D180  
(expiring)

**0000-4564**

The D180 ceiling manifold box is the adapter between up to a maximum of 12 DucoFlex D63 ducts and a direct connection to a D180 riser duct. The smart 'Click & Go' system provides a quick and perfectly airtight joint between DucoFlex ducts.



DucoFlex Riser duct connector, round D160 > 2x oval

**0000-4566**

The riser duct connector can be utilised multifunctionally. It is an adapter between 2x DucoFlex oval and a D160 riser duct. In combination with connectors D63, D75 or D90, it becomes a floor/ceiling plenum.



DucoFlex Adapter 3x63 oval

**0000-4684**

DucoFlex Adapter 2x75 oval

**0000-4685**

DucoFlex Adapter 3x75 oval

**0000-4841**

DucoFlex Adapter 2x90 oval

**0000-4686**

The adapter allows connecting 3x DucoFlex D63/D75 or 2x DucoFlex D75/D90 to a DucoFlex oval connection. The smart "Click & Go" system provides a quick and perfectly airtight joint between DucoFlex ducts.



DucoFlex Rigid oval ducting W163 x H68 x L1150

**0000-4567**

Rigid DucoFlex oval ducting combined with the D160 - 2x oval connector enables a manifold box to be provided in a favourable location.



DucoFlex Horizontal elbow 90°/45° Rigid oval duct

**0000-4609**

The horizontal bend in the standard configuration enables a 90° bend to be made in rigid oval ducting. It is possible to cut this component down to a 45° bend.



DucoFlex Vertical elbow 90° Rigid oval duct

**0000-4699**

The vertical elbow in the standard version enables a vertical 90° bend to be made in rigid oval ducting.



DucoFlex Oval duct coupling

**0000-4568**

The oval coupling provides a quick and perfectly airtight connection between DucoFlex oval ducting and connections.



DucoFlex horizontal connector D125 oval

**0000-4638**

The D125 oval connector provides a horizontal connection between D125 round duct and DucoFlex oval duct or an optional connector for DucoFlex.



DucoFlex Horizontal connector 2x Oval D160

**0000-4700**

The D160 2x oval connector provides a horizontal connection between D160 round ducts and 2x DucoFlex oval ducts or an optional connector for DucoFlex.



DucoFlex oval cap

**0000-4713**

The DucoFlex oval cap makes it possible to close an oval connection of a manifold box

## TOOLS



DucoFlex Duct cutter D63

**0000-4599**

DucoFlex Duct cutter D75

**0000-4688**

DucoFlex Duct cutter D90

**0000-4689**

The DucoFlex duct cutter ensures that ducting can be cut easily as well as nice and straight. This is recommended for airtight system assembly.



## INSULATED DUCTING

|  |                  |
|--|------------------|
| DucoFlex Insulated circular duct with integrated coupler D125 L1000 mm<br><b>available Q1/2026</b> | <b>0000-7082</b> |
|--|------------------|

|  |                  |
|--|------------------|
| DucoFlex Insulated circular duct with integrated coupler D160 L1000 mm | <b>0000-4569</b> |
|--|------------------|

|  |                  |
|--|------------------|
| DucoFlex Insulated circular duct with integrated coupler D180 L1000 mm | <b>0000-4909</b> |
|--|------------------|

|  |                  |
|--|------------------|
| DucoFlex Insulated circular duct with integrated coupler D200 L1000 mm | <b>0000-4905</b> |
|--|------------------|

The DucoFlex Insulated circular duct is a smooth and insulated ventilation duct made of EPS. The good insulating properties of this product prevent a thermal bridge and therefore condensation when polluted air is extracted or outside air is supplied. Energy losses from ventilation air are also avoided. In addition to the good thermal insulation value, the material used also dampens noise and is very easy to handle. A connection piece is supplied as standard which connects the various EPS components quickly and airtight.



|  |                  |
|--|------------------|
| DucoFlex Insulated 90° bend with integrated coupler D125<br><b>available Q1/2026</b> | <b>0000-7083</b> |
|--|------------------|

|  |                  |
|--|------------------|
| DucoFlex Insulated 90° bend with integrated coupler D160 | <b>0000-4571</b> |
|--|------------------|

|  |                  |
|--|------------------|
| DucoFlex Insulated 90° bend with integrated coupler D180 | <b>0000-4910</b> |
|--|------------------|

|  |                  |
|--|------------------|
| DucoFlex Insulated 90° bend with integrated coupler D200 | <b>0000-4906</b> |
|--|------------------|

The DucoFlex Insulated 90° bend is a smooth and insulated elbow for ventilation ducts made of EPS. The good insulating properties of this product prevent a thermal bridge and therefore condensation when polluted air is extracted or outside air is supplied. Energy losses from ventilation air are also avoided. In addition to the good thermal insulation value, the material used also dampens noise and is very easy to handle. A connection piece is supplied as standard which connects the various EPS components quickly and airtight.



|  |                  |
|--|------------------|
| DucoFlex Insulated 45° bend with integrated coupler D125<br><b>available Q1/2026</b> | <b>0000-7084</b> |
|--|------------------|

|  |                  |
|--|------------------|
| DucoFlex Insulated 45° bend with integrated coupler D160 | <b>0000-4573</b> |
|--|------------------|

|  |                  |
|--|------------------|
| DucoFlex Insulated 45° bend with integrated coupler D180 | <b>0000-4911</b> |
|--|------------------|

|  |                  |
|--|------------------|
| DucoFlex Insulated 45° bend with integrated coupler D200 | <b>0000-4907</b> |
|--|------------------|

The DucoFlex Insulated 45° bend is a smooth and insulated elbow for ventilation ducts made of EPS. The good insulating properties of this product prevent a thermal bridge and therefore condensation when polluted air is extracted or outside air is supplied. Energy losses from ventilation air are also avoided. In addition to the good thermal insulation value, the material used also dampens noise and is very easy to handle. A connection piece is supplied as standard which connects the various EPS components quickly and airtight.



|   |                  |
|---|------------------|
| DucoFlex Insulated coupler D125<br><b>available Q1/2026</b> | <b>0000-7085</b> |
|---|------------------|

|                                 |                  |
|---------------------------------|------------------|
| DucoFlex Insulated coupler D160 | <b>0000-4575</b> |
|---------------------------------|------------------|

|                                 |                  |
|---------------------------------|------------------|
| DucoFlex Insulated coupler D180 | <b>0000-4912</b> |
|---------------------------------|------------------|

|                                 |                  |
|---------------------------------|------------------|
| DucoFlex Insulated coupler D200 | <b>0000-4908</b> |
|---------------------------------|------------------|

The DucoFlex Insulated coupler is a practical connection piece that connects the various EPS components in a quick and airtight manner.

## CONNECTION PIECES



|   |                  |
|---|------------------|
| Connection piece with joint D125/D125 (M/M)<br><b>available Q2/2026</b> | <b>0000-7086</b> |
|---|------------------|

|   |                  |
|---|------------------|
| Connection piece with joint D160/D125 (M/M)<br><b>available Q2/2026</b> | <b>0000-7087</b> |
|---|------------------|

|   |                  |
|---|------------------|
| Connection piece with joint D160/D160 (M/M) | <b>0000-4724</b> |
|---|------------------|

|   |                  |
|---|------------------|
| Connection piece with joint D180/D160 (M/M) | <b>0000-4725</b> |
|---|------------------|

|   |                  |
|---|------------------|
| Connection piece with joint D180/D180 (M/M) | <b>0000-4726</b> |
|---|------------------|

|   |                  |
|---|------------------|
| Connection piece with joint D200/D180 (M/M) | <b>0000-4727</b> |
|---|------------------|

|   |                  |
|---|------------------|
| Connection piece 45° with joint D160/D160 (M/M) | <b>0000-4949</b> |
|---|------------------|

The connection pieces with joint are used to make a quick and good connection between ducts (extraction and/or supply) or between a duct and a DucoBox. Thanks to the pre-fitted rubber seal, an airtightness class of up to D can be guaranteed at the connection!



|   |           |
|---|-----------|
| Insulated connection piece with joint D125/D125 (M/M)<br><span style="background-color: #90EE90; border-radius: 50%; padding: 2px 5px; display: inline-block;">available Q2/2026</span> | 0000-7135 |
| Insulated connection piece with joint D160/D125 (M/M)<br><span style="background-color: #90EE90; border-radius: 50%; padding: 2px 5px; display: inline-block;">available Q2/2026</span> | 0000-7136 |
| Insulated connection piece with joint D160/D160 (M/M)   | 0000-7039 |
| Insulated connection piece with joint D180/D160 (M/M)   | 0000-7040 |
| Insulated connection piece with joint D180/D180 (M/M)   | 0000-7041 |
| Insulated connection piece with joint D200/D180 (M/M)   | 0000-7042 |
| Insulated connection piece 45° with joint D160/D160 (M/M)   | 0000-7043 |

The connection pieces with joint are used to make a quick and good connection between ducts (extraction and/or supply) or between a duct and a DucoBox. Thanks to the pre-fitted rubber seal, an airtightness class of up to D can be guaranteed at the connection!



## SILENCERS



|  |           |
|--|-----------|
| DucoFlex Silencer flexible D125 L1000 mm | 0000-4586 |
|--|-----------|

The DucoFlex Silencer D125 is a (semi-) flexible silencer composed of a flexible antibacterial inner duct (non-woven) and a polyester-laminated aluminium outer jacket. The space between the inner and outer jacket is filled with 25 mm sound absorbing material.

Both ends are taped to allow the silencer to be easily connected to the ventilation unit or the rigid ventilation ducts of diameter D125.



|  |           |
|--|-----------|
| DucoFlex Silencer flexible D125 (M/F) L1000 mm | 0000-4630 |
| DucoFlex Silencer flexible D200 (M/F) L1000 mm | 0000-4918 |

The DucoFlex Silencer (M/F) is a (semi-)flexible silencer consisting of a flexible antibacterial inner channel (non-woven) and an aluminium outer jacket laminated in polyester. The space between the inner and outer jacket is filled with 25 mm sound absorbing material.

The silencer comes standard with stainless steel caps on both ends of which 1 M and 1 F connection. This allows quick, easy and airtight connection of the damper to the ventilation unit or rigid ventilation ducts of diameter D125 or D200.



|  |           |
|--|-----------|
| DucoFlex Silencer flexible D125 (M/M) L1000 mm<br><span style="background-color: #90EE90; border-radius: 50%; padding: 2px 5px; display: inline-block;">available Q1/2026</span> | 0000-7088 |
|--|-----------|

|  |           |
|--|-----------|
| DucoFlex Silencer flexible D160 (M/M) L1000 mm | 0000-4631 |
| DucoFlex Silencer flexible D180 (M/M) L1000 mm | 0000-4632 |

The DucoFlex Silencer (M/M) is a (semi-) flexible silencer composed of a flexible antibacterial inner duct (non-woven) and a polyester-laminated aluminium outer jacket. The space between the inner and outer jacket is filled with 25 mm sound absorbing material. The silencer is provided with stainless steel caps on both ends (2 x M connection). This allows the silencer to be connected quickly, easily and airtight to the ventilation unit or the rigid ventilation ducts of diameter D125, D160 or D180.



|  |           |
|--|-----------|
| DucoFlex Silencer semi rigid D125 (M/M) L1000 mm<br><span style="background-color: #90EE90; border-radius: 50%; padding: 2px 5px; display: inline-block;">available Q1/2026</span> | 0000-7089 |
|--|-----------|

|  |           |
|--|-----------|
| DucoFlex Silencer semi rigid D160 (M/M) L1000 mm | 0000-4587 |
| DucoFlex Silencer semi rigid D180 (M/M) L1000 mm | 0000-4588 |
| DucoFlex Silencer semi rigid D200 (M/M) L1000 mm | 0000-4919 |

The DucoFlex Silencer semi-rigid (M/M) is a semi-rigid (bendable) silencer composed of a profiled and perforated aluminium inner duct and a two-layered profiled outer jacket. The space between the inner and outer jacket is filled with 50 mm sound absorbing material.

The silencer is provided with aluminium caps on both ends (2 x M connection). This allows quick, easy and airtight connection of the damper to the ventilation unit or rigid ventilation ducts of diameter D125, D160, D180 or D200.

## RECOMMENDED RANGE OF APPLICATION

| DucoFlex ducts |   | Other components |                                       |
|----------------|---|------------------|---------------------------------------|
| Ø63            | up to 25 m <sup>3</sup> /h (7 l/s) per ducts  | Ø125             | up to 150 m <sup>3</sup> /h (42 l/s)  |
| Ø75            | up to 36 m <sup>3</sup> /h (10 l/s) per ducts | Ø160             | up to 250 m <sup>3</sup> /h (69 l/s)  |
| Ø90            | up to 50 m <sup>3</sup> /h (14 l/s) per ducts | Ø180             | up to 350 m <sup>3</sup> /h (97 l/s)  |
|                |   | Ø200             | up to 550 m <sup>3</sup> /h (153 l/s) |



## VENTS

The vents are installed in ducts for the extraction of stale air or supply of fresh air. DUCO does not lose sight of the aesthetic or the functional aspect here either.





## WHICH VENTS TO CHOOSE?

|                     | DucoVent <b>Basic</b><br>see p. 94   | DucoVent <b>Comfort</b><br>see p. 94   | DucoVent <b>Design</b><br>see p. 95  | DucoVent <b>Premium</b><br>see p. 94                   | Trimless                      | Trim  |
|---------------------|--|--|--|--|-------------------------------|-------|
| Type of DucoBox     | DucoBox <b>Reno</b><br>DucoBox <b>Silent (Connect)</b><br>DucoBox <b>Focus</b><br>DucoBox <b>Energy Comfort (Plus)</b><br>DucoBox <b>Energy Sky</b><br>DucoBox <b>Energy Premium</b> |  |  |  |                               |       |
| Type of vent        | Supply<br>Extraction   | Supply<br>Extraction   | Supply*<br>Extraction<br><small>* With the exception of 'Standard' vents</small>       | Supply<br>Extraction                                   |                               |       |
| Air flow            | Up to 75 m <sup>3</sup> /h   | Extraction:<br>up to 75 m <sup>3</sup> /h<br><br>Supply:<br>up to 75 m <sup>3</sup> /h | Extraction:<br>up to 75 m <sup>3</sup> /h<br><br>Supply:<br>up to 50 m <sup>3</sup> /h | Up to 50 m <sup>3</sup> /h                             |                               |       |
| Design              | ★  | ★★★  | ★★★★   | ★★★★★<br>★★  | ★★★★                          | ★★★★★ |
| Shape               | Round  | Round  | Round<br>Square<br>Standard and XL<br>Rounded Square<br>Standard and XL                | Round  |                               |       |
| Material            | Plastic  | Plastic (ASA)  | Aluminium  | Plastic  |                               |       |
| Colour              | White  | White  | All RAL  | White<br>(can be painted)<br>or black                  |                               |       |
| Sound absorption    | ★  | ★★★★   | ★★★★★  | ★★★★★  |                               |       |
| Ease of maintenance | ★★   | ★★★  | ★★★★★  | ★★★★   |                               |       |
| Fitting             | To be clamped in<br>DucoFlex   | Sealing joint in<br>DucoFlex   | To be clamped in<br>DucoFlex   | Sealing joint<br>in DucoFlex<br>Trimless: + plastering |                               |       |
| Setting flow rate   | Fine adjustment<br>via rotary adjuster   | 11 adjustable<br>positions   | Preregulation<br>with flow rings<br>+<br>Fine adjustment<br>via rotary adjuster        | 32<br>adjustable<br>positions                          | 34<br>adjustable<br>positions |       |
| Price               | €  | €€   | €€€€   | €€€€   | €€€                           |       |

Extraction

Supply

**STANDARD VENT** All systems**DucoVent Basic**

The DucoVent Basic is the standard vent that is manufactured from plastic and is suitable for ceiling and wall mounting. Fine adjustment is by means of a cone that screws in and out. Suitable for both extraction and supply.

|   |               |                             |
|---|---------------|-----------------------------|
| Maximum flow rate: 75 m <sup>3</sup> /h | Colour: White | Connection diameter: 125 mm |
|---|---------------|-----------------------------|



Suitable for

DucoVent Basic

Extraction  
+ Supply

0000-4178

Extraction

Supply

**STANDARD VENT** All systems**DucoVent Comfort**

A vent where both aesthetics and ease of adjustment are central. This is what DucoVent Comfort stands for! Thanks to a clever principle of adjustment positions, the vent can be adjusted both in advance and during installation. The ideal addition to all Duco ventilation systems in serial construction where the copy function saves a lot of time!

|   |               |                             |
|---|---------------|-----------------------------|
| Maximum flow rate: 75 m <sup>3</sup> /h | Colour: White | Connection diameter: 125 mm |
|---|---------------|-----------------------------|



Suitable for

DucoVent Comfort

Extraction  
+ Supply

0000-4769

Extraction

Supply

**STANDARD VENT** All systems**DucoVent Premium Trimless**

(by Prado)

The DucoVent Premium Trimless is by far the finest vent in the market that can be used for both supply and extraction. A 'trimless' integration into the plasterwork makes the vent almost invisible. The well-thought-out design ensures a diffuse air supply via the Coanda effect and therefore guarantees optimal comfort. Aesthetics and quality in one product! A perfect combination with DUCO's high-quality ventilation solutions!

|   |  |                             |
|---|--|-----------------------------|
| Maximum flow rate: 50 m <sup>3</sup> /h | Colour: White (can be painted over), Black | Connection diameter: 125 mm |
|---|--|-----------------------------|



Suitable for

DucoVent Premium Trimless **White**Extraction  
+ Supply

0000-4903

DucoVent Premium Trimless **Black**Extraction  
+ Supply

0000-7105

available Q2/2026



# DucoVent Premium Trim

(by Prado)

The DucoVent Premium Trim offers the most extensive control options with 34 adjustable positions and is suitable for both supply and extraction.

Thanks to a minimal mounting height and paintable visible parts, the valve virtually merges into the ceiling. The well-thought-out design ensures a diffuse air supply via the Coanda effect and therefore guarantees optimum comfort. Aesthetics and quality in one product! A perfect combination with DUCO's high-quality ventilation solutions!

|                            |  |                             |
|----------------------------|--|-----------------------------|
| Maximum flow rate: 50 m³/h | Colour: White (can be painted over), Black | Connection diameter: 125 mm |
|----------------------------|--|-----------------------------|



Geschikt voor

|   |                            |                  |
|---|----------------------------|------------------|
| DucoVent Premium Trim <b>White</b>                      | <b>Extraction + Supply</b> | <b>0000-5004</b> |
| DucoVent Premium Trim <b>Black</b><br>available Q2/2026 | <b>Extraction + Supply</b> | <b>0000-7106</b> |



## Plasterboard sleeve

This accessory enables the installation of the DucoVent Premium Trim Ø 125 in plasterboard ceilings when connected to flexible ducts.

|  |                  |
|--|------------------|
| Plasterboard sleeve Ø 125<br>available Q2/2026 | <b>0000-7098</b> |
|--|------------------|

Extraction

Supply

## SOUND ABSORBING DESIGN VENT All systems

# DucoVent Design

The DucoVent Design is an **aesthetic vent**, available with five different cover plates: square (standard and XL), rounded square (standard and XL) or fully circular. The sleek design, combined with simple installation thanks to its magnetic fastening, ensures **virtually invisible integration** into any room where air extraction or supply is provided. The acoustic rings provide optimal **sound reduction** and easy calibration. Suitable for ceiling and wall mounting. Easy to clean without disturbing the settings.

The DucoVent Design Round and all XL models are also suitable for use as supply vents. Two inserts are included which can be used to reduce the supply angle, when positioning the vent close to a wall or in a corner, for example.

|  |  |
|--|--|
| Maximum flow rate:<br>Extraction: 75 m³/h<br>Supply: 50 m³/h | Noise level: <15 dB(A) at 50 m³/h<br>Colour: White (RAL 9010 structure (AE03059901020)), other RAL colours on request<br>Duct diameter: 125 mm |
|--|--|



## Square

|   |                                       |                            |                  |
|---|---------------------------------------|----------------------------|------------------|
| DucoVent Design Square <b>Standard AK</b> | Width / Height: 180mm<br>Depth: 52mm  | <b>Extraction</b>          | <b>0000-7006</b> |
| DucoVent Design Square <b>XL AK</b>       | Width / Height: 215 mm<br>Depth: 52mm | <b>Extraction + Supply</b> | <b>0000-7007</b> |



## Round

|                                 |                                |                            |                  |
|---------------------------------|--------------------------------|----------------------------|------------------|
| DucoVent Design Round <b>AK</b> | Diameter: 215mm<br>Depth: 52mm | <b>Extraction + Supply</b> | <b>0000-7008</b> |
|---------------------------------|--------------------------------|----------------------------|------------------|



## Rounded

|   |                                       |                            |                  |
|---|---------------------------------------|----------------------------|------------------|
| DucoVent Design Rounded Square <b>Standard AK</b> | Width / Height: 180mm<br>Depth: 52mm  | <b>Extraction</b>          | <b>0000-7012</b> |
| DucoVent Design Rounded Square <b>XL AK</b>       | Width / Height: 215 mm<br>Depth: 52mm | <b>Extraction + Supply</b> | <b>0000-7013</b> |



## AIR FLOW

DUCO supplies a wide range of grilles for extraction and supply for every conceivable use. Please refer to the DUCO website for the complete range.



Please refer to our website for more supply and feed-through options. DUCO offers a wide range of products ranging from standard self-regulating grilles which can be fitted in any kind of window or installation situation, including grilles with sound deadening, fire-resistant grilles, customised grilles for high-rise buildings, as well as ventilation and solar shading in a single product or electronically-controlled grilles with preheating.



MEV system

## FEED-THROUGH VIA FACADE Inside + outside

### Silenzio

The Silenzio is a wall damper that is excellent for **renovation**. Not only has its appearance been given a complete makeover, but from now on the Silenzio also features an SR flap so it can easily be used in one of our ventilation systems. This **sound absorbing** ventilator has been developed specifically for situations where high noise levels are an issue.

The Silenzio SR and Silenzio Retro SR are **suitable for wall thicknesses from 250 mm**. For a deviant pipe length, contact your DUCO dealer.

For more information such as drawings, flow rates and other specifications, consult the brochure "Window and sound-absorbing ventilation" or [www.duco.eu](http://www.duco.eu).

|   |  |   |
|---|--|---|
| <p><b>Diameter of tube:</b> 250 mm<br/> <b>Length of tube:</b> 300 mm (suitable for wall thicknesses from 250 mm)<br/> For a deviant pipe length, contact your DUCO dealer.</p> | <p><b>Silenzio SR</b><br/> <b>Interior and exterior colours:</b> standard RAL 9010, other RAL colours possible on request.<br/> <b>Maximum flow rate:</b><br/> Silenzio SR: 59.4 m<sup>3</sup>/h (2 Pa)<br/> Silenzio SR AK: 36.4 m<sup>3</sup>/h (2 Pa)</p> | <p><b>Silenzio Retro SR</b><br/> <b>Colour of inner part:</b> standard RAL 9010, other RAL colours available on request.<br/> <b>Colour DUCO external louvre grille:</b> RAL 7048 (mother of pearl mouse grey)<br/> <b>Maximum flow rate:</b><br/> Without external louvre grille: 54.7 m<sup>3</sup>/h (2 Pa)<br/> With DUCO external louvre grille: 46.5 m<sup>3</sup>/h (2 Pa)</p> |
|---|--|---|



#### Silenzio SR

The AK variant is extra sound absorbing.

|                |                  |
|----------------|------------------|
| Silenzio SR    | <b>7352-4055</b> |
| Silenzio SR AK | <b>7372-4055</b> |



#### Silenzio Retro SR

The retro variant is specifically suitable for listed buildings with a protected façade. This grille integrates invisibly into the façade (by means of a weep hole) or can be fitted with a discreet external louvre grille (DUKO external louvre grille or external section of your choice).

|   |                  |
|---|------------------|
| Silenzio Retro SR <b>without external louvre grille</b>   | <b>7512-4055</b> |
| Silenzio Retro SR <b>with DUCO external louvre grille</b> | <b>7502-4055</b> |



MEV system

MVHR system

## FEED-THROUGH VIA FACADE Outside

## DucoFlex Wall feed-through

The DucoFlex Wall feed-through can be used as a supply and extraction point with **very low pressure losses**. The fitted flange with a diameter of 125, 160, 180 or 200 provides a quick and air-tight connection to the DucoFlex ISO D125, 160, 180 or 200 pipes without any need for **connecting pieces**. The pre-fitted condensation strip prevents the possible undesired settling of dripping condensate. The sleek design and black or white colour enable the unit to be used discretely in **any type of façade**.



|   | White     | Black     |
|---|-----------|-----------|
| DucoFlex Wall feed-through <b>D125</b><br>available Q1/2026 | 0000-7090 | 0000-7091 |
| DucoFlex Wall feed-through <b>D160</b>                      | 0000-4627 | 0000-4584 |
| DucoFlex Wall feed-through <b>D180</b>                      | 0000-4628 | 0000-4585 |
| DucoFlex Wall feed-through <b>D200</b>                      | 0000-4913 | 0000-4914 |

MEV system


## FEED-THROUGH VIA FACADE Inside

## DucoGrille Close M100

DucoGrille Close M 100 is a **closable** surface mounted internal louvre grille. The plastic slides provide adjustable ventilation. Thanks to the small punching, this grille is **insect repellent**.

These products are also available in other sizes and colours. If interested, we would like to refer you to our sister company Duco Projects NV.

Material: aluminium | Colour: anodisation SAA (15-20 µm)



|                        | Width (mm) | Height (mm) |          |
|------------------------|------------|-------------|----------|
| DucoGrille Close M 100 | 200        | 200         | S5501001 |

A = Width x Height (see table) | B = 12 mm | C = 13 mm



MEV system

MVHR system

## FEED-THROUGH VIA DOOR

### DoorVent

The DoorVent is a transfer grille that **can be installed discretely in internal doors**. Unlike gaps under the door, the DoorVent thereby avoids draughts and **attenuates intrusive noise**.

**Dimensions:**

Overall (Width x Height):

436 x 58 mm

Recessed fitting (Width x Height):

417 x 48 mm

Airflow: 70 cm<sup>2</sup>

Door thickness: 37-47 mm



DoorVent **RAL 9001**

**1030-0800**

DoorVent **RAL 9010**

**1030-0700**

DoorVent **other DUCO300RAL**

**1030-0500**

RAL colours other than those described above on request.

MEV system

MVHR system

## FEED-THROUGH VIA FACADE Outside

### DucoGrille Solid 30Z

The height and width of these **customised grilles** can be determined to the millimetre, both in rectangular and round format. The DucoGrille Solid 30Z is vandal-resistant thanks to its **extra sturdy louvres** and can also be made burglary-resistant. Available for various construction situations (recessed, surface mounted, glass replacement) and in variants with vermin and insect protection.

See the Brochure 'Louvre Grilles' for more information, and feel free to get in touch with our sister company Duco Projects NV, marketing these specific products.





MEV system

MVHR system


## FEED-THROUGH VIA INTERIOR WALL &amp; DOOR

## DucoGrille Transfer

This **transfer grille** can easily be installed in **doors and walls**. The frame depth can be adjusted. The grille can be fitted **with or without a counterframe**. The DucoGrille Transfer is ideally suited for larger airflows between interior spaces, but can also be used between interior and exterior spaces (e.g. exterior doors).

These products are also available in other sizes and colours. If interested, we would like to refer you to our sister company Duco Projects NV.


Material: aluminium | Colour: aluminium colour



## Without counterframe

| Width (mm) | Height (mm) |          |
|------------|-------------|----------|
| 190        | 90          | S5201001 |
| 290        | 90          | S5201002 |
| 290        | 190         | S5201003 |
| 390        | 90          | S5201004 |
| 390        | 190         | S5201005 |
| 390        | 290         | S5201006 |
| 490        | 290         | S5201007 |
| 590        | 390         | S5201008 |


A = Width x Height (see table) | B = 21 mm | C = 36 mm | D = 31 mm



## With counterframe (wall depth 28-54 mm)

| Width (mm) | Height (mm) |          |
|------------|-------------|----------|
| 200        | 100         | S5301001 |
| 300        | 100         | S5301002 |
| 300        | 200         | S5301003 |
| 400        | 100         | S5301004 |
| 400        | 200         | S5301005 |
| 400        | 300         | S5301006 |
| 500        | 300         | S5301007 |
| 600        | 400         | S5301008 |

A = Width x Height (see table) | B = 21 mm | C = 36 mm | D = 28-54 mm



## With counterframe (wall depth 54-84 mm)

| Width (mm) | Height (mm) |          |
|------------|-------------|----------|
| 200        | 100         | S5401001 |
| 300        | 100         | S5401002 |
| 300        | 200         | S5401003 |
| 400        | 100         | S5401004 |
| 400        | 200         | S5401005 |
| 400        | 300         | S5401006 |
| 500        | 300         | S5401007 |
| 600        | 400         | S5401008 |

A = Width x Height (see table) | B = 21 mm | C = 36 mm | D = 54-84 mm

Systeem C

Systeem D

## DOORVOER VIA PLAT & HELLEND DAK

### DucoFlex Dakdoorvoer



|  | Slate            | Terracotta       |
|--|------------------|------------------|
| DucoFlex Roof feed-through Compact D125 -<br><span style="background-color: #2e6b2e; color: white; padding: 2px 5px;">available Q1/2026</span> | <b>0000-7092</b> | <b>0000-7093</b> |
| DucoFlex Roof feed-through Compact D160  | <b>0000-4582</b> | <b>0000-4580</b> |
| DucoFlex Roof feed-through Compact D200  | <b>0000-4920</b> | <b>0000-4921</b> |

The DucoFlex Roof feed-through Compact can be used as a supply and extraction point. The dark grey or terracotta colour and the design allow this unit to be used very discretely in a **sloping roof**. The pre-fitted lead sheet ensures quick and water-tight installation.

The smart design ensures that this compact roof feed-through is hardly sensitive to atmospheric turbulences. The connection piece fits seamlessly into DucoFlex ISO pipes D125, D160 or D200.




|  |                  |
|--|------------------|
| DucoFlex Universal Roof feed-through D125 (1,0m)<br><span style="background-color: #2e6b2e; color: white; padding: 2px 5px;">available Q1/2026</span>  | <b>0000-7094</b> |
| DucoFlex Universal Roof feed-through D160/180 (1.0m)]<br>(expiring - to be replaced by 0000-7095 Q1)   | <b>0000-4578</b> |
| DucoFlex Universal Roof feed-through D160 (1,0m)]<br><span style="background-color: #2e6b2e; color: white; padding: 2px 5px;">available Q1/2026</span> | <b>0000-7095</b> |
| DucoFlex Universal Roof feed-through D180/200 (1,0m)   | <b>0000-4915</b> |

The DucoFlex Universal Roof feed-through can be used as a supply and extraction point on **both flat and sloping roofs**. This unit can also be used at higher air flow rates thanks to its low air-resistance. The pre-assembled connection piece is 635 mm, allowing the roof feed-through to be used in any possible situation. The insulated end piece fits DucoFlex ISO D125, D160, D180 and D200 pipes.



|   |                  |
|---|------------------|
| DucoFlex Dakdoorvoer plakplaat plat dak D160<br><span style="background-color: #2e6b2e; color: white; padding: 2px 5px;">available Q1/2026</span> | <b>0000-7096</b> |
| DucoFlex Dakdoorvoer plakplaat plat dak D204<br>(expiring - to be replaced by 0000-7108 Q1)   | <b>0000-4581</b> |
| DucoFlex Dakdoorvoer plakplaat plat dak D230<br><span style="background-color: #2e6b2e; color: white; padding: 2px 5px;">available Q1/2026</span> | <b>0000-7108</b> |
| DucoFlex Dakdoorvoer plakplaat plat dak D263  | <b>0000-4916</b> |

The DucoFlex adhesive plate for **flat roofs** can be combined with the Universal Roof feed-throughs. It is made completely of aluminium, making it suitable for all standard finishes of roof feed-throughs on flat roofs.



|   |                  |
|---|------------------|
| DucoFlex Universal Roof feed-through tile D160<br><span style="background-color: #2e6b2e; color: white; padding: 2px 5px;">available Q1/2026</span> | <b>0000-7097</b> |
| DucoFlex Universal Roof feed-through tile D205*<br>(expiring - to be replaced by 0000-7109 Q1)  | <b>0000-4579</b> |
| DucoFlex Universal Roof feed-through tile D227<br><span style="background-color: #2e6b2e; color: white; padding: 2px 5px;">available Q1/2026</span> | <b>0000-7109</b> |
| DucoFlex Universal Roof feed-through tile D263  | <b>0000-4917</b> |

The DucoFlex Universal Roof feed-through tile can be combined with the Universal Roof feed-throughs. The unit is suitable for **sloping roofs**. The pre-fitted plastic flashing ensures quick and water-tight installation.

## COMBINATION OPTIONS FOR ROOF FEED-THROUGHS

| Type DucoFlex<br>Universal roof feed-through |             | For sloping roofs:<br>Matching DucoFlex roof feed-through tile |                      |             | For flat roofs: Matching<br>DucoFlex adhesive plate |             |
|--|-------------|--|----------------------|-------------|---|-------------|
| Product                                      | Item number | Product  | Angle of inclination | Item number | Product   | Item number |
| D125 (1.0 m)                                 | 0000-7094   | D160   | 15-55°               | 0000-7097   | D160  | 0000-7096   |
| D160 (1.0 m)                                 | 0000-7095   | D227   | 15-50°               | 0000-7109   | D230  | 0000-7108   |
| D180/200 (1.0 m)                             | 0000-7095   | D263   | 20-50°               | 0000-4917   | D263  | 0000-4916   |

# PART F

## BUILDING REGULATIONS

Please find below the ventilation requirements in line with Part F of the building regulations for UK & Ireland

### UK

A continuous rate is given for the general operation of the fan and a high rate for when additional extraction is required.

#### **Minimum extract ventilation rates for continuous extract systems<sup>1</sup>:**

| Room                   | High rate (L/S) | Continuous rate  |
|------------------------|-----------------|--|
| Kitchen                | 13              | The sum of all extract ventilation in the dwelling on its continuous rate should be at least the whole dwelling ventilation rate given in the table below. |
| Utility Room           | 8               |  |
| Bathroom               | 8               |  |
| Sanitary accommodation | 6               |  |

<sup>1</sup> If the continuous rate of ventilation provided in a room is equal to or higher than the minimum high rate specified in the table, no extra ventilation is needed.

The minimum whole dwelling ventilation rate for the supply of air to the habitable rooms in a dwelling should meet both of the following conditions

- A minimum rate of 0.3 litres per second per m<sup>2</sup> of internal floor area
- A minimum rate determined by the number of bedrooms, as specified in the below table.

#### **Minimum whole dwelling ventilation rates determined by the number of bedrooms:**

| Number of bedrooms <sup>2</sup> | Minimum ventilation rate by number of bedrooms (l/s) |
|---------------------------------|--|
| 1                               | 19   |
| 2                               | 25   |
| 3                               | 31   |
| 4                               | 37   |
| 5                               | 43   |

<sup>2</sup> If the dwelling only has one habitable room, a minimum ventilation rate of 13 l/s should be used. For each additional bedroom, add 6 l/s to the values in the table above.

## Ireland

The minimum capacity of a centralized continuous ventilation system should be based on the calculated general ventilation rate. The calculated general ventilation rate to be provided by is determined as the greater of:

- 5 l/s plus 4 l/s per person, e.g. 25 l/s for a five person, 3-bedroom semi-detached dwelling. This is based on two occupants in the main and second bedrooms, and a single occupant in the third bedroom. This should be used as the default value, if a greater level of occupancy is expected, then add 4 l/s per occupant.

OR

- 0.3 l/s per m<sup>2</sup> internal floor area, e.g. 30 l/s for a 100 m<sup>2</sup> dwelling.

In order to meet extract requirements, the system may require a higher extract or boost capacity depending on the number of wet rooms (kitchens, bathrooms, etc.) and sanitary accommodation. The minimum boost extract rate to be provided for each wet room and sanitary accommodation is specified in the table below. The required overall minimum boost extract rate is calculated by adding together the relevant individual extract rates.

### Centralized continuous mechanical extract ventilation systems: minimum boost extract rates<sup>3</sup>

| Wet rooms                                  | Minimum extract rate (l/s) |
|--|----------------------------|
| Kitchen                                    | 13 <sup>4</sup>            |
| Utility Room                               | 8                          |
| Bathroom                                   | 8                          |
| Sanitary accommodation (no bath or shower) | 6 <sup>5</sup>             |

<sup>3</sup> The above are minimum boost extract rates and may need to be increased to achieve the general ventilation rate.

<sup>4</sup> Excludes cooker hood extract.

<sup>5</sup> As an alternative, an opening window provided for purge ventilation may be relied on for extract.

### (only for MVHR)

Supply and extract rates should be nominally balanced. Airflow supply rates should be greater or equal to extract rates. In all cases, the supply airflow rate should be no greater than 15% above extract airflow rate.

# SERVICE PLEASE!

## STUDY SERVICE Tailored advice

Thanks to years of know-how in the field of ventilation, DUCO's design department has all the **expertise in house** to offer the installation best suited to your project. For this purpose please contact your trusted DUCO distributor or DUCO contact, or submit your project via the website:

[www.duco.eu/yourproject](http://www.duco.eu/yourproject)



## HELP DESK Let yourself be guided

Your DUCO dealer is available to provide you with **support for all possible practical challenges**. If you need support during design or installation, feel free to consult them: their experts are trained by DUCO.

[info@duco.eu](mailto:info@duco.eu)



## DUCO.TV Instructional videos

Our **short instruction videos** will help you step-by-step during installation or maintenance of DUCO products.

[duco.tv](http://duco.tv)



## BIM LIBRARY Consult online

The construction market is becoming increasingly centralised and thus efficiently managed with BIM as a guiding principle. DUCO has anticipated this since the early days by making an **Autodesk Revit product library** available online. In addition, DUCO products are also included in the internationally oriented platform **BIM Object**.

[duco.eu/bim](http://duco.eu/bim)

[www.bimobject.com](http://www.bimobject.com)

## NOTES


# INSTALLATION TIPS

## DUCOBLOCK RENO / SILENT CONNECT / FOCUS

The proper functioning of your DUCO ventilation system depends entirely on the choice and quality of the exhaust duct system!

Has the duct system been optimized? Seek professional advice from your duct supplier. It saves you time, guarantees quality and provides an energy benefit for the end user!

**DISCLAIMER:** no rights can be derived from this document. All tips are advisory only. Each contractor may determine at their own discretion which tips are feasible and/or useful, depending on the project.




# INSTALLATION TIPS

## DUCOBLOCK ENERGY COMFORT (PLUS) / SKY / PREMIUM

The correct operation of your DUCO ventilation system is entirely dependent on the choice and build quality of the supply and exhaust ducts!

Has the duct system been optimized? Ask professional advice from your duct supplier. It saves you time, ensures quality and provides energetic advantage for the end user!

**DISCLAIMER:** no rights can be derived from this document. All tips are only advisory. All those carrying out the work can, depending on the project at hand, determine for themselves which tips are feasible and/or useful.



# Small. Smart. Green.

DucoBox Energy Comfort (Plus) D250

